
SECTION 5A

AUTOMATIC TRANSMISSION

CAUTION: Disconnect the negative battery cable before removing or installing any electrical unit or when a tool or equipment could easily come in contact with exposed electrical terminals. Disconnecting this cable will help prevent personal injury and damage to the vehicle. The ignition must also be in LOCK unless otherwise noted.

TABLE OF CONTENTS

Description and Operation	5A-2	Shift Quality Faults	5A-45
BTRA M74 4WD Automatic Transmission	5A-2	After Teardown Faults	5A-47
Operators Interfaces	5A-2	Trouble Code Diagnosis - Gasoline Vehicle	5A-50
Control Systems	5A-3	TCM Diagnostic System Overview	5A-50
Electronic Control System	5A-3	Clearing Trouble Codes	5A-50
Hydraulic Control System	5A-10	Diagnostic Trouble Codes	5A-50
Hydraulic Control Circuit	5A-11	Trouble Code Diagnosis - Diesel Vehicle	5A-52
Power Train System	5A-15	TCM Diagnostic System Overview	5A-52
Power Flows	5A-19	Clearing Trouble Codes	5A-52
Park and Neutral	5A-20	Diagnostic Trouble Codes	5A-52
Reverse	5A-22	Repair Instructions	5A-159
Manual 1	5A-24	On-Vehicle Service	5A-159
Drive 1	5A-26	Transmission	5A-159
Drive 2 and Manual 2	5A-28	Unit Repair	5A-162
Drive 3 and Manual 3	5A-30	Rebuild Warnings	5A-162
Drive 3 Lock Up and Manual 3 Lock Up	5A-32	Disassembly Procedure	5A-163
Drive 4 (Overdrive)	5A-34	Assembly Procedure	5A-173
Drive 4 Lock Up	5A-36	Front and Rear Band Adjustment	5A-201
Diagnostic Information and Procedures	5A-38	Gear Shift Control Lever	5A-204
Diagnosis	5A-38	Kickdown Switch	5A-205
Basic Knowledge Required	5A-38	Transmission Control Module	5A-205
Functional Check Procedure	5A-38	Specifications	5A-206
Transmission Fluid Level Service Procedure	5A-38	General Specification	5A-206
Fluid Leak Diagnosis and Repair	5A-39	Fastener Tightening Specifications	5A-210
Electrical / Garage Shift Test	5A-40	Schematic and Routing Diagrams	5A-211
Road Test Procedure	5A-40	TCM Wiring Diagrams (Gasoline Engine)	5A-211
Electronic Adjustments	5A-41	TCM Wiring Diagrams (Diesel Engine)	5A-213
Symptom Diagnosis	5A-42	Connector End View	5A-215
Drive Faults	5A-42	Special Tools and Equipment	5A-216
Faulty Shift Pattern	5A-43	Special Tools Table	5A-216

DESCRIPTION AND OPERATION

BTRA M74 4WD AUTOMATIC TRANSMISSION

The BTR Automotive Model 74 Four Speed Automatic Transmission is an electronically controlled overdrive four speed unit with a lock-up torque converter. The lock-up torque converter results in lower engine speeds at cruise and eliminates unnecessary slippage. These features benefit the customer through improved fuel economy and noise reduction.

	Max. Power (kW)	Configuration
320	160	260 mm Torque Converter-Wide Ratio Gear Set Splined Output for Transfer Case


Of primary significance is the Transmission Control Module (TCM) which is a microprocessor based control system.

The TCM utilizes throttle position, rate of throttle opening, engine speed, vehicle speed, transmission fluid temperature, gear selector position and mode selector inputs, and in some applications a Kickdown Switch to control all shift feel and shift schedule aspects.

The TCM drives a single proportional solenoid multiplexed to three regulator valves to control all shift feel aspects. The output pressure of this solenoid is controlled as a function of transmission fluid temperature to maintain consistent shift feel throughout the operating range.

Shift scheduling is highly flexible, and several independent schedules are programmed depending on the vehicle.

Typically the NORMAL schedule is used to maximize fuel economy and driveability, and a POWER schedule is used to maximize performance. WINTER schedule is used to facilitate starting in second gear.



OPERATORS INTERFACES

There are three operator interfaces as the following;

- Gear Shift Control Lever
- Driving Mode Selector
- Indicator Light

Gear Shift Control lever

The transmission uses a conventional shift control lever. The gear shift control lever can be moved from one position to another within the staggered configuration of the shift control lever gate to positively indicate the gear selection.

- P - Park position prevents the vehicle from rolling either forward or backward by locking the transmission output shaft. The inhibitor switch allows the engine to be started. For safety reasons, the parking should be used in addition to the park position. Do not select the Park position until the vehicle comes to a complete stop because it mechanically locks the output shaft.
- R - Reverse allows the vehicle to be operated in a rearward direction. The inhibitor switch enables reverse lamp operation.
- N - Neutral allows the engine to be started and operated while driving the vehicle. The inhibitor switch


allows the engine to be started. There is no power transferred through the transmission in Neutral. But the final drive is not locked by the parking pawl, so the wheels are free to rotate.

- D - Overdrive range is used for all normal driving conditions. 4th gear (overdrive gear) reduces the fuel consumption and the engine noise. Engine braking is applied with reduced throttle.

First to second (1 → 2), first to third (1 → 3), second to third (2 → 3), second to fourth (2 → 4), third to fourth (3 → 4), fourth to third (4 → 3), fourth to second (4 → 2), third to second (3 → 2), third to first (3 → 1) and second to first (2 → 1) shifts are all available as a function of vehicle speed, throttle position and the time change rate of the throttle position.

Downshifts are available for safe passing by depressing the accelerator. Lockup clutch may be enabled in 3rd and 4th gears depending on vehicle type.

- 3 - Manual 3 provides three gear ratios (first through third) and prevents the transmission from operating in 4th gear. 3rd gear is used when driving on long hill roads or in heavy city traffic. Downshifts are available by depressing the accelerator.
- 2 - Manual 2 provides two gear ratios (first and second). It is used to provide more power when climbing hills or engine braking when driving down a steep hill or starting off on slippery roads.
- 1 - Manual 1 is used to provide the maximum engine braking when driving down the severe gradients.



Driving Mode Selector

The driving mode selector consists of a driving mode selector switch and indicator light. The driving mode selector is located on the center console and allows the driver to select the driving mode.

The driving modes available to be selected vary with vehicle types. Typically the driver should have the option to select among NORMAL, POWER and WINTER modes.

When NORMAL mode is selected upshifts will occur to maximize fuel economy. When POWER mode is selected, upshifts will occur to give maximum performance and the POWER mode indicator light is switched ON.

When WINTER mode is selected, starting in second gear is facilitated, the WINTER mode indicator light is switched ON and the POWER mode indicator light is switched OFF.

Indicator Light

The indicator light is located on the instrument panel.

- Auto shift indicator light comes ON when the ignition switch ON and shows the gear shift control lever position.
- POWER mode indicator light comes ON when the POWER mode is selected and when the kickdown switch is depressed.
- WINTER mode indicator light comes ON when the WINTER mode is selected.

CONTROL SYSTEMS

BTRA M74 4WD automatic transmission consists of two control systems. One is the electronic control system that monitors vehicle parameters and adjusts the transmission performance. Another is the hydraulic control system that implements the commands of the electronic control system commands.

ELECTRONIC CONTROL SYSTEM

The electronic control system comprises of sensors, a TCM and seven solenoids. The TCM reads the inputs and activates the outputs according to values stored in Read Only Memory (ROM).

The TCM controls the hydraulic control system. This control is via the hydraulic valve body, which contains seven electromagnetic solenoids. Six of the seven solenoids are used to control the line pressure, operate the shift valves and the torque converter lock-up clutch, and to turn ON and OFF the two regulator valves that control the shift feel.

The seventh solenoid is the proportional or Variable Pressure Solenoid (VPS) which works with the two regulator valves to control shift feel.

Transmission Control Module (TCM)

The TCM is an in-vehicle micro-processor based transmission management system. It is mounted under the driver's side front seat in the vehicle cabin.

The TCM contains:

- Processing logic circuits which include a central microprocessor controller and a back-up memory system.
- Input circuits.

5A-4 AUTOMATIC TRANSMISSION

- Output circuits which control external devices such as the Variable Pressure Solenoid (VPS) driver, On/Off solenoid drivers, a diagnostics output and the driving mode indicator light.

Processing Logic

Shift schedule and calibration information is stored in an Erasable Programmable Read Only Memory (EPROM). Throttle input calibration constants and the diagnostics information are stored in Electrically Erasable Programmable Read Only Memory (EEPROM) that retains the memory even when power to the TCM is disconnected. TCM continuously monitors the input values and uses these, via the shift schedule, to determine the required gear state. At the same time it monitors, via the solenoid outputs, the current gear state, whenever the input conditions change such that the required gear state is different to the current gear state, the TCM initiates a gear shift to bring the two states back into line.

Once the TCM has determined the type of gearshift required the TCM accesses the shift logic, estimates


the engine torque output, adjusts the variable pressure solenoid ramp pressure then executes the shift.

The TCM continuously monitors every input and output circuit for short or open circuits and operating range.

When a failure or abnormal operation is detected the TCM records the condition code in the diagnostics memory and implements a Limp Home Mode (LHM).

The actual limp home mode used depends upon the failure detected with the object to maintain maximum drive-ability without damaging the transmission. In general input failures are handled by providing a default value. Output failures, which are capable of damaging the transmission, result in full limp mode giving only third or fourth gear and reverse. For further details of limp modes and memory retention refer to the Diagnostic Trouble Code Diagnosis Section.

The TCM is designed to operate at ambient temperatures between - 40 and 85 °C (- 40 and 185 °F). It is also protected against electrical noise and voltage spikes, however all the usual precautions should be observed, for example when arc welding or jump starting.



TCM Inputs

To function correctly, the TCM requires engine speed, vehicle speed, transmission fluid temperature, throttle position, gear position and Kickdown Switch inputs to determine the variable pressure solenoid current ramp

and on/off solenoid states. This ensures the correct gear selection and shift feel for all driving conditions. The inputs required by the TCM are as follows;

• Engine Speed

The engine speed signal is derived from the Controller Area Network (CAN) via Engine Control Module (ECM).

• Vehicle Speed


The vehicle speed sensor, which is located in the transfer case, sends the output shaft speed signal to the Engine Control Module (ECM). The information is then transferred to the TCM via the CAN.

• Transmission Fluid Temperature

The transmission fluid temperature sensor is a thermistor located in the solenoid wiring loom within the valve body of the transmission. This sensor is a typical Negative Temperature Coefficient (NTC) resistor with low temperatures producing a high resistance and high temperatures producing a low resistance.


If the transmission fluid temperature exceeds 135 °C (275 °F), the TCM will impose converter lock-up at lower vehicle speeds and in some vehicles flashes the mode indicator light. This results in maximum oil flow through the external oil cooler and eliminates slippage in the torque converter. Both these actions combine to reduce the oil temperature in the transmission.

Temperature (°C)	Resistance (Ohms)	
	Minimum	Maximum
-20	13,638	17,287
0	5,177	6,616
20	2,278	2,723
100	117	196
135 (Overheat Mode Threshold)	75	85



Pin No. Codes and colors in Solenoid Loom

Pin No.	Wire Color	Connects to
1	Red	Solenoid 1
2	Blue	Solenoid 2
3	Yellow	Solenoid 3
4	Orange	Solenoid 4
5	Green	Solenoid 5
6	Violet	Solenoid 6
7	Brown	Solenoid 7
8	Green	Solenoid 5
9	White	Temperature Sensor
10	Red	Temperature Sensor



Throttle Position Sensor

Gasoline Engine:

The throttle position signal is sent from the ECM to the TCM via the CAN. Refer to Engine Section for further details.

Diesel Engine:

The throttle position sensor (TPS) is a resistance potentiometer which is installed on the injection pump. It transmits a signal to the TCU proportional to the throttle plate opening.

The potentiometer is connected to the TCU by three wires: 5 volts positive supply, earth and variable wiper voltage.

Throttle voltage adjustments are as follows:


- Closed throttle voltage is 0.2 V to 1.0 V.
- Wide open throttle voltage is 3 V to 4.5 V.

These measurements are taken between pins 1 and 3 of the TPS connector.

5A-6 AUTOMATIC TRANSMISSION


Maintaining good shift feel through the transmission life span is dependant on having an accurate measure of the engine throttle position. To achieve this the TCU continuously monitors the maximum and minimum throttle potentiometer voltages and, if a change occurs, stores the new voltage values.

However these limits will be lost and will require relearning should a new TCU be installed, or the throttle calibration data is cleared by the execution of a particular sequence. This last instance depends on the installation, and reference should be made to the Diagnostics Section of this manual. The relearning will happen automatically.



Gear Position Sensor

The gear position sensor is incorporated in the inhibitor switch mounted on the side of the transmission case.



The gear position sensor is a multi-function switch providing three functions;

- Inhibit starting of the vehicle when the shift lever is in a position other than Park or Neutral
- Illuminate the reverse lamps when Reverse is selected
- Indicate to the TCM which lever position has been selected by way of a varying resistance.

Readings for Resistance / Shift Lever Positions

Shift Lever Position	Resistance (k Ω)
Manual 1	1 ~ 1.4
Manual 2	21.8 ~ 2.2
Manual 3	3.3 ~ 3.4
Drive	4.5 ~ 4.9
Neutral	6.8 ~ 7.2
Reverse	10.8 ~ 11.2
Park	18.6 ~ 19

Kickdown Switch

The Kickdown Switch is used to signal the TCM that the driver has pressed the accelerator to the floor and requires a kickdown shift. When this switch is used, the POWER light comes ON and the POWER shift pattern is used.

Diagnostic Inputs

The diagnostic control input or K-line is used to initiate the outputting of diagnostic data from the TCM to a diagnostic test instrument. This input may also be used to clear the stored fault history data from the TCM's retentive memory. Connection to the diagnostic input of the TCM is via a connector included in the vehicle's wiring harness or computer interface.

Battery Voltage Monitoring Input

The battery voltage monitoring input is connected to the positive side of the battery. This signal is taken from the main supply to the TCM.

If the battery voltage at the TCM falls below 11.3 V, the transmission will adopt a low voltage mode of operating in which shifts into first gear are inhibited. All other shifts are allowed but may not occur because of the reduced voltage. This condition normally occurs only when the battery is in poor condition.

If the battery voltage is greater than 16.5 V, the transmission will adopt limp home mode and all solenoids are turned OFF.

When system voltage recovers, the TCM will resume normal operation after a 30 seconds delay period.

TCM Outputs

The outputs from the TCM are supplied to the components described below;

- Solenoids
- Mode Indicator Light

Solenoids

The TCM controls seven solenoids. Solenoids 1 to 6 (S1 to S6) are mounted in the valve body, while Solenoid 7 (S7) is mounted in the pump cover.

- Solenoid 1 and 2: S1 and S2 are normally open ON/OFF solenoids that set the selected gear. These solenoids determine static gear position by operating the shift valves. Note that S1 and S2 solenoids also send signal pressure to allow or prohibit rear band engagement.
- Solenoid 3 and 4: S3 and S4 are normally open ON/OFF solenoids that combine to control shift quality and sequencing. S3 switches the clutch regulator valve OFF or ON. S4 switches the front band regulator valve OFF or ON. S5 also provides the signal pressure for the converter clutch regulator valve.
- Solenoid 5: S5 is a variable pressure solenoid that ramps the pressure during gear changes. This solenoid provides the signal pressure to the clutch and band regulator, thereby controlling the shift pressures. S5 also provides the signal pressure for the converter clutch regulator valve.

- Solenoid 6: S6 is a normally open ON/OFF solenoid that sets the high/low level of line pressure. Solenoid OFF gives high pressure.
- Solenoid 7: S7 is a normally open ON/OFF solenoid that controls the application of the converter clutch. Solenoid ON activates the clutch.

Solenoid Logic for Static Gear States

Gear	S1	S2
1st	ON	ON
2nd	OFF	ON
3rd	OFF	OFF
4th	ON	OFF
Reverse	OFF	OFF
Neutral	OFF	OFF
Park	OFF	OFF

5A-8 AUTOMATIC TRANSMISSION

Solenoid Operation during Gearshifts

Shift	To Initiate Shift	Typical S5 Current Ramp	To Complete Shift
1-2	S1 OFF S4 ON	750mA to 600mA	S4 OFF
1-3	S1 OFF S2 OFF S3 ON S4 ON	850mA to 750mA	S3 OFF S4 OFF
1-4	S2 OFF S3 ON S4 ON	850mA to 750mA	S3 OFF S4 OFF
2-3	S2 OFF S3 ON S4 ON	700mA to 500mA	S3 OFF S4 OFF
3-4	S1 ON S4 ON	750mA to 600mA	S4 OFF
4-3	S4 ON	750mA to 900mA	S1 OFF S4 OFF
4-2	S3 ON	750mA to 950mA	S1 OFF S2 ON S3 OFF
4-1	S3 ON S4 ON	600mA to 1000mA	S2 ON S3 OFF S4 OFF
3-2	S2 ON S4 ON	600mA to 450mA @ 20 kph. 550mA to 400mA @ 60 kph. 800mA to 650mA @ 100 kph.	S4 OFF
3-1	S3 ON S4 ON	700mA to 950mA	S1 ON S2 ON S3 OFF S4 OFF
2-1	S4 ON	800mA to 950mA	S1 ON S4 OFF
Conv. Clutch ON OFF	S7 ON	700mA to 400mA 600mA to 100mA	S7 OFF

Solenoid Valve Symbols


(ON/OFF Solenoids)

The solenoid symbol shown adjacent to each solenoid on the hydraulic system schematics indicates the state of the oil flow through the solenoid valve with the power ON or OFF.

Normally Open (NO) Solenoid

POWER ON: Line 500 port is closed. The output port is open to exhaust at the solenoid valve.

POWER OFF: The exhaust port is closed. The output port is open to line 500.



Variable Pressure Solenoid Multiplexing System

Friction element shifting pressures are controlled by the Variable Pressure Solenoid (VPS).

Line pressure is completely independent of shift pressure and is a function of throttle position, gear state and engine speed.

S5 is a proportional or variable pressure solenoid that provides the signal pressure to the clutch and band regulator valves thereby controlling shift pressures.

VPS pressure is multiplexed to the clutch regulator valve, the band regulator valve and the converter clutch regulator valve during automatic gearshifts.

A variable pressure solenoid produces a hydraulic pressure inversely proportional to the current applied. During a gearshift the TCM applies a progressively increasing or decreasing (ramped) current to the solenoid. Current applied will vary between a minimum of 200 mA and a maximum of 1000 mA. Increasing current decreases output (S5) pressure. Decreasing current increases output (S5) pressure.

Line 500 pressure, (approximately 440 to 560 kPa), is the reference pressure for the VPS, and the VPS output pressure is always below line 500 pressure.

When the VPS is at standby, that is no gearshift is taking place, the VPS current is set to 200 mA giving maximum output pressure.

Under steady state conditions the band and clutch regulator valve solenoids are switched OFF.

This applies full Line 500 pressure to the plunger and because Line 500 pressure is always greater than S5 pressure it squeezes the S5 oil out between the regulator valve and the plunger. The friction elements are then fed oil pressure equal to Line 500 multiplied by the amplification ratio.

When a shift is initiated the required ON/OFF solenoid is switched ON cutting the supply of Line 500 to the plunger.

At the same time the VPS pressure is reduced to the ramp start value and assumes control of the regulator valve by pushing the plunger away from the valve. The VPS then carries out the required pressure ramp and the timed shift is completed by switching OFF the ON/OFF solenoid and returning the VPS to the standby pressure.

This system enables either the band or clutch or both to be electrically controlled for each gearshift.

Mode Indicator Light

Depending on the application, the mode indicator light may be used to indicate the mode that has been selected or if an overheat condition exists. The mode indicator light is usually located on the instrument cluster.

Communication Systems

CAN

The Controller Area Network (CAN) connects various control modules by using a twisted pair of wires, to share common information. This results in a reduction of sensors and wiring. TCM obtains the actual engine speed and throttle position, vehicle speed and accelerator position etc. from ECM via CAN without any additional sensors.

K-Line

The K-line is typically used for obtaining diagnostic information from the TCM. A scan tool with a special interface is connected to the TCM via Data Link Connector (DLC) and all current faults, stored faults, runtime parameters are then available. The stored trouble codes can also be cleared by scan tool.

The K-line can be used for vehicle coding at the manufacturer's plant or in the workshop. This allows for one TCM design to be used over different vehicle models.

The particular code is sent to the microprocessor via the K-line and this results in the software selecting the correct shift and VPS ramp parameters.


Data Link Connector (DLC)

The Data Link Connector (DLC) is a multiple cavity connector. The DLC provides the means to access the serial data from the TCM.

The DLC allows the technician to use a scan tool to monitor the various systems and display the Diagnostic Trouble Codes (DTCs).

5A-10 AUTOMATIC TRANSMISSION

The DLC connector is located within the driver's compartment, directly below the instrument panel on the driver's side.



HYDRAULIC CONTROL SYSTEM

The hydraulic controls are located in the valve body, pump body and main case.

The valve body contains the following;

- Manual valve
- Three shift valves
- Sequence valve
- Solenoid supply pressure regulator valve
- Line pressure control valve
- Clutch apply feed regulator valve
- Band apply feed regulator valve
- Solenoid S1 to S6
- Reverse lockout valve

The pump cover contains the following;

- Primary regulator valve for line pressure
- Converter clutch regulator valve
- Converter clutch control valve
- Solenoid S7

The main case contains the following;

- B1R exhaust valve

All upshifts are accomplished by simultaneously switching on a shift valve(s), switching VPS pressure to the band and/or clutch regulator valve, and then sending the VPS a ramped current. The shift is completed by switching the regulators OFF and at the same time causing the VPS to reach maximum pressure.

All downshifts are accomplished by switching VPS pressure to the band and/or clutch regulator valve and sending a ramped current to the VPS. The shift is completed by simultaneously switching the regulators OFF, switching the shift valves and at the same time causing the VPS to return to stand-by pressure.


The primary regulator valve is located in the pump cover and supplies four line pressures; high and low for forward gears, and high and low for reverse. This pressure has no effect on shift quality and merely provides static clutch capacity during steady state operation. Low pressure can be obtained by activating an ON/OFF solenoid with high line pressure being the default mode.

Torque converter lock-up is initiated by toggling the converter clutch control valve with an ON/OFF solenoid.

The actual apply and release of the clutch is regulated by the VPS via the converter clutch regulator valve.

The solenoid supply pressure regulator valve provides reference pressure for all the solenoids.


HYDRAULIC CONTROL CIRCUIT



KAA5A08A


5A-12 AUTOMATIC TRANSMISSION

Valve Body



Manual Valve

The manual valve is connected to the vehicle selector mechanism and controls the the flow of oil to the forward and reverse circuits. The manual valve function is identical in all forward gear positions except that in the Manual 1 position an additional supply of oil is directed to the 1-2 shift valve for application of the rear band and the C4 overrun clutch. The manual valve directs the line pressure into the PRND fluid circuits.




1-2 Shift Valve

The 1-2 shift valve is a two position valve that must be switched to the 2, 3 and 4 position in order to get any forward gear other than first gear. It is used for all 1-2 and 2-1 gearshifts.

The switching of this valve is achieved by using S1 and/or S2.

During a 1-2 gearshift drive oil from the manual valve passes through to the second gear circuit. During a 2-1 gearshift the band apply feed oil is allowed to exhaust via the 1-2 shift valve.

The 1-2 shift valve works in conjunction with the 3-4 shift valve to disengage the C4 clutch in first gear, and engage C4 in second gear. When Manual 1 is selected the C4 clutch and rear band (B2) are engaged.




2-3 Shift Valve

The 2-3 shift valve is a two position valve. It is used on all 2-3 and 3-2 gearshifts.

The switching of this valve is achieved by S2 which is located at the end of the valve spool.

In the 1, 2 position, second gear oil from the 1-2 shift valve is prevented from entering the third gear circuit.

When the valve is moved to the 3, 4 position, oil from the second gear circuit is routed to the third gear circuit and the transmission is changed to third gear.



3-4 Shift Valve

The 3-4 shift valve is a two position valve. It is used for all 3-4 and 4-3 gearshifts.

The switching of this valve is achieved by S1 which is located at the end of the valve spool.


During a 3-4 gearshift the 3-4 shift valve:

- Exhausts the front band release (B1R) circuit thereby allowing the application of the front band (B1).
- Connects the inner apply area of the front servo (B1A1) to the Band Apply Feed (BAF) circuit thus allowing greater apply forces to the front band.
- Exhausts the Overrun Clutch (OC) circuit which allows the C4 clutch to disengage.

During a 4-3 gearshift, the C4 clutch is engaged and the front band (B1) is released. These actions are sequenced by the 4-3 sequence valve.

The 3-4 shift valve also switches during 1-2 and 2-1 gearshifts where its function is to apply the overrun clutch (C4) in second gear but to release it in first gear.


Note that the C4 clutch is applied in Manual 1 by virtue of the manual valve and the 1-2 shift valve. Refer to "1-2 Shift Valve" in this section.



4-3 Sequence Valve

The 4-3 sequence valve is a two position spring loaded valve. It switches during 3-4 and 4-3 gearshifts although it performs no function during the 3-4 shift.

During the 4-3 shift the 4-3 sequence valve delays the connection of the Clutch Apply Feed (CAF) circuit to the B1R circuit until the B1R circuit has been fully pressurized by using the third gear circuit. This prevents objectionable engine flare on completion of the 4-3 gearshift.



Solenoid Supply Pressure Regulator Valve


The solenoid supply pressure regulator valve supplies a constant pressure to all solenoids (S1 to S7). Line pressure is used as the feeding oil to this regulator and the output is termed line 500.

Line Pressure Control Valve

Line pressure is controlled by S6, which acts as the

line pressure control valve. When S6 pressure is applied to the end of the Primary Regulator Valve (PRV), it is opposed by spring force and causes LOW line pressure for light throttle application and cruising.


Heavy throttle application causes the normally open S6 to open (switch Off) thus closing line 500 and opening S6 to exhaust. Removal of S6 pressure from the PRV results in HIGH line pressure.



Clutch Apply Feed Regulator Valve

The clutch apply feed regulator valve is a fixed ratio (2.25:1) valve. This valve provides a regulated pressure to the C1 clutch and controls the change rate of the clutch state to give the desired shift quality.


Third gear oil supplied to the valve is regulated to provide an output pressure, Clutch Apply Feed (CAF) pressure, of 2.25 times the S5 signal pressure when S3 is ON. When S3 is OFF, the output pressure is 2.25 times the line 500 pressure.



Band Apply Feed Regulator Valve

The band apply feed regulator valve is a fixed ratio (1.4:1) valve. It provides a regulated pressure to the front servo, and controls the change rate of the front band (B1) state to give the desired shift quality.


Second gear oil supplied to the valve is regulated to provide an output pressure, Band Apply Feed (BAF) pressure, of 1.4 times the S5 signal pressure when S4 is ON. When S4 is OFF the output pressure is 1.4 times the line 500 pressure.



Reverse Lockout Valve

The reverse lockout valve is a two position valve contained in the upper valve body. This valve uses S1-S2 pressure as a signal pressure and controls the application of the rear band (B2).

While the manual valve is in D, 3, 2 or 1 positions, drive oil is applied to the spring end of the valve, overriding any signal pressures and holding the valve in the lockout position. This prevents the application of B2 in any of the forward driving gears except M1.



When the manual valve is in P, R or N positions, drive oil is exhausted and the reverse lockout valve may be toggled by S1-S2 pressure.

B2 is applied in P, R, and N if the following conditions are satisfied;

- In P or N, vehicle speed = 3 km/h.
- In R, vehicle speed = 10 km/h.
- Engine speed = 1600 rpm.
- Throttle position = 12 %.

Under these conditions, the TCM switches solenoids S1 and S2 to OFF. The reverse lockout valve toggles under the influence of the S1-S2 pressure, to connect the line pressure to the B2 feed. Oil is fed to both the inner and outer apply areas of the rear servo piston, applying B2.


If any of the above conditions are not satisfied, the TCM switches solenoids S1 and S2 to ON.

S1- S2 pressure is exhausted and the valve is held in the lockout position by the spring. In this position, engagement of B2 is prohibited.

This feature protects the transmission from abuse by preventing the undesirable application of B2 at high speed, and by providing a reverse lockout function.

Note that if the transmission is in failure mode, the rear band will be applied at all times in P, R and N.

Pump Cover



Primary Regulator Valve


The Primary Regulator Valve (PRV) regulates the transmission line pressure (or pump output pressure). This valve gives either high or low line pressure depending on whether S6 is switched OFF or ON. When S6 is switched ON, S6 pressure is applied to the PRV moving it against spring pressure and opening the line pressure circuit to the pump suction port resulting in reduced line pressure.

Low line pressure is used during light throttle applications and cruising. Heavy throttle will cause S6 to switch OFF and thereby cause high line pressure.

This stepped line pressure control has no detrimental effect on shift feel because all shifting pressures are controlled by separate band and clutch regulator valves, and the output of S5.


When reverse gear is selected, both the low and high line pressure values are boosted to guard against slippage. This is achieved by applying reverse oil line pressure to the PRV to assist the spring load. The other end of the valve contains ports for line pressure feedback and S6 pressure.

The PRV also regulates the supply of oil to the converter via the converter feed port. The cascade effect of the PRV ensures the first priority of the valve is to maintain line pressure at very low engine speeds. When the engine speed increases and the pump supplies an excess of oil the PRV moves to uncover the converter feed port thereby pressurizing the converter. If there is an excess of oil for the transmission's needs then the PRV moves further to allow oil to return to the suction port.



Converter Clutch Regulator Valve

The converter clutch regulator valve regulates the pressure of the oil which applies the converter clutch. Input oil from the line 500 circuit is regulated within the valve, with the output pressure being variable according to the signal pressure from the S5 circuit. Converter clutch apply and release application is smoothed by electronically varying the S5 circuit pressure.




Converter Clutch Control Valve

The converter clutch control valve is a two position valve which applies or releases the converter clutch. The switching of this valve is governed by the signal pressure from S7.


When the valve is in the OFF or released position, converter feed oil from the PRV is directed to the release side of the converter clutch. After flowing through the converter, oil returns to the converter clutch control valve and is then directed to the oil cooler.

When the valve is in the ON or applied position, regulated oil from the converter clutch regulator valve is directed to the apply side of the converter clutch. This oil remains within the converter because the converter clutch piston is sealed against the flat friction surface of the converter cover. To provide oil flow to the cooler the converter clutch control valve directs converter feed oil from the PRV directly to the cooler circuit.



B1R Exhaust Valve

The B1R exhaust valve is a two position spring loaded valve located in the transmission case directly adjacent to the front servo. It permits the servo release oil to be rapidly exhausted into the transmission case during application of the front band (B1). This prevents the need to force the oil back from the front servo through the valve body and through the 3-4 shift valve. The spring positions the valve to prevent oil entering the release area of the servo until the B1R circuit oil pressure reaches approximately 100 kPa.



POWER TRAIN SYSTEM

The Power Train System consists of;

- A torque converter with single face lock-up clutch
- Four multi-plate clutch assemblies
- Two brake bands
- Two one-way clutches
- Planetary gear set
- Parking mechanism

A conventional six pinion Ravigneaux compound planetary gear set is used with overdrive (fourth gear) being obtained by driving the carrier.

The cross-sectional arrangement is very modular in nature.

Four main sub-assemblies are installed within the case to complete the build. These subassemblies are;

5A-16 AUTOMATIC TRANSMISSION

- Gear set-sprag-centre support
- C1 -C2 -C3 -C4 clutch sub-assembly
- Pump assembly
- Valve body assembly

One, or a combination of selective washers are used between the input shaft flange and the number 4 bearing to control the transmission end float. This arrangement allows for extensive subassembly testing and simplistic final assembly during production.

A general description of the operation of the Power Train System is detailed below.

First gear is engaged by applying the C2 clutch and locking the 1-2 One Way Clutch (1-2 OWC). The 1-2 shift is accomplished by applying the B1 band and overrunning the 1-2 OWC. The 2-3 shift is accomplished by applying the C1 clutch and releasing

the B1 band. The 3-4 shift is accomplished by re-applying the B1 band and overrunning the 3-4 OWC. Reverse gear is engaged by applying the C3 clutch and the B2 band.


The C4 clutch is applied in the Manual 1, 2 and 3 ranges to provide engine braking. In addition, the C4 clutch is also applied in the Drive range for second and third gears to eliminate objectionable freewheel coasting.

The B2 band is also applied in the Manual 1 range to accomplish the low-overrun shift.

Both the front and rear servos are dual area designs to allow accurate friction element matching without the need for secondary regulator valves. All the friction elements have been designed to provide low shift energies and high static capacities when used with the new low static co-efficient transmission fluids. Non-asbestos friction materials are used throughout.

Gear	Gear Ratio	ELEMENTS ENGAGED								
		C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
First	2.741		X					X	X	
Second	1.508		X			X			X	
Third	1.000	X	X		X	X			X	X*
Fourth	0.708	X	X		X				X	X
Reverse	2.428			X			X			
Manual 1	2.741		X		X		X		X	

* For Certain Vehicle Applications, Refer to the Owner's Manual.




KAA5A250

Torque Converter

The torque converter consists of a turbine, stator pump, impeller and a lock-up damper and piston assembly. As in conventional torque converters, the impeller is attached to the converter cover, the turbine is splined to the input shaft and the stator is mounted on the pump housing via a one way clutch (sprag).

The addition of the damper and piston assembly enables the torque converter to lock-up under favorable conditions. Lock-up is only permitted to occur in third and fourth gears under specified throttle and vehicle speed conditions.

Lock-up is achieved by applying hydraulic pressure to the damper and piston assembly which couples the turbine to the converter cover, locking-up the converter and eliminating unwanted slippage. Whenever lock-up occurs, improved fuel consumption is achieved. Torsional damper springs are provided in the damper and piston assembly to absorb any engine torque fluctuations during lock-up.



Clutch Packs


There are four clutch packs. All clutch packs are composed of multiple steel and friction plates.

C1 CLUTCH: When applied, this clutch pack allows the input shaft to drive the planet carrier. This occurs in third and fourth gears.

C2 CLUTCH: When applied this clutch pack allows the input shaft to drive the forward sun gear via the 3-4 OWC. This occurs in all forward gears.

C3 CLUTCH: When applied this clutch pack allows the input shaft to drive the reverse sun gear. This only occurs in reverse gear.

C4 CLUTCH: When applied this clutch provides engine braking on overrun. This occurs in Manual 1, 2 and 3 and also Drive 2 and Drive 3 to prevent objectionable free wheel coasting.



5A-18 AUTOMATIC TRANSMISSION



Bands

The transmission utilizes two bands, the B1 band (sometimes known as the 2-4 band), and the B2 band (sometimes known as the low-reverse band).

The B1 band is a flexible band which is engaged by the front servo piston. B1 is activated in second and fourth gear. When activated B1 prevents the reverse sun gear from rotating by holding the C3 clutch assembly stationary. In second gear only the outer

area of the apply piston is utilized. In fourth gear both areas are utilized for greater clamping force.

The B2 band is a solid band which is engaged by the rear servo piston. B2 is activated in Park, Reverse, Neutral and Manual 1. When activated B2 prevents the planet carrier assembly from rotating. In Manual 1 only the inner area of the apply piston is utilized. In Park, Reverse and Neutral, both areas are utilized for greater clamping force.



One Way Clutches

The transmission uses two OWCs, the 1-2 OWC and the 3-4 OWC. (Note that a third OWC is located in the torque converter, also known as a sprag.)

The 1-2 OWC is located between the planetary carrier assembly and the center support. This allows the carrier to rotate around the center support in one direction only. The one way clutch is engaged only in Drive 1.


This 3-4 OWC is located between the C4 and the C2 clutch assemblies. This allows the C2 clutch to drive the forward sun gear in first, second and third gears but unlocks in fourth gear and during overrun.

Planetary Gear Set

The planetary gear set used in the transmission is a conventional six pinion Ravigneaux compound gear set.

Parking Mechanism

When Park is selected the manual lever extends the park rod rearwards to engage the parking pawl. The pawl will engage the external teeth on the ring gear thus locking the output shaft to the transmission case. When Park is not selected a return spring holds the parking pawl clear of the output shaft, preventing accidental engagement of Park.



POWER FLOWS

The power flows for the various transmission selections are listed below;

- Power Flow - Neutral and Park
- Power Flow - Reverse
- Power Flow - Manual 1
- Power Flow - Drive 1
- Power Flow - Drive 2

- Power Flow - Drive 3
- Power Flow - Drive 3 Lock Up
- Power Flow - Drive 4 (Overdrive)
- Power Flow - Drive 4 Lock Up

The following table details the engaged elements versus the gear selected for all transmission selections.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Park and Neutral	-	-	-	-	-	X	-	-	-
Reverse	-	-	X	-	-	X	-	-	-
Manual 1	-	X	-	X	-	X	-	X	-
Drive 1	-	X	-	-	-	-	X	X	-
Drive 2 and Manual 2	-	X	-	X	X	-	-	X	-
Drive 3 and Manual 3	X	X	-	X	-	-	-	X	-
Drive 3 Lock Up and Manual 3 Lock Up	X	X	-	X	-	-	-	X	X
Drive 4 Overdrive	X	X	-	-	X	-	-	X	-
Drive 4 Lock Up	X	X	-	-	X	-	-	X	X

Power Flow - Park and Neutral

In Park and Neutral, there is no drive to the planetary gear set. The rear band is applied to eliminate ‘clunk’ on engagement of the reverse gear, and to improve the low range engagement for 4WD applications. No other clutches or bands are applied.

In Park the transmission is mechanically locked by engaging a case mounted pawl with teeth on the output shaft ring gear.


Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows:

- Solenoids S1 and S2 are switched OFF.


- Line (pump) pressure is applied to the Primary Regulator Valve (PRV) and to the solenoid supply pressure regulator valve.
- The converter, oil cooler, and lubrication circuits are charged from the primary regulator valve.
- The line 500 circuit is charged by the solenoid supply pressure regulator valve.
- The S5 circuit is charged by the variable pressure solenoid (S5).
- Line pressure is prevented from entering the drive circuit by the manual valve.
- The B1 circuit and all clutch circuits are open to exhaust.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Park and Neutral	-	-	-	-	-	X	-	-	-



5A-22 AUTOMATIC TRANSMISSION

REVERSE



Power Flow - Reverse

In Reverse, transmission drive is via the input shaft and the forward clutch cylinder to the hub of the C3 clutch. The elements of the transmission function as follows;


- The C3 clutch is engaged and drives the reverse sun gear in a clock-wise direction.
- The B2 band is engaged and holds the planetary gear carrier stationary causing the long pinion to rotate anti-clockwise about its axis on the pinion shaft.
- The long pinion drives the internal ring gear in the same direction.
- The internal ring being splined to the output shaft drives it in an anti-clockwise or reverse direction.

Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows;


- Solenoids S1 and S2 are switched OFF.
- Line pressure is directed through the reverse lockout valve to both the inner and outer apply areas of the rear servo piston for B2 band application.
- Line pressure feeds the reverse oil circuit via the manual valve.
- Reverse oil is routed from the manual valve to the C3 clutch.
- Reverse oil is also applied to the spring end of the primary regulator valve to assist the spring and to boost the line pressure value.
- All other clutch and band apply circuits are open to exhaust.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Reverse	-	-	X	-	-	X	-	-	-



KAA5A340

MANUAL 1



KAA5A35A

Power Flow - Manual 1

In Manual 1, transmission drive is via the input shaft to the forward clutch cylinder. The elements of the transmission function as follows;


- The C2 clutch is engaged to drive the forward sun gear, via the 3-4 OWC.
- The B2 band is engaged to hold the planetary gear carrier stationary.
- The forward sun gear drives the short pinion anti-clockwise.
- The short pinion drives the long pinion clockwise.
- The long pinion rotating about its axis drives the internal ring gear and the output shaft in a clockwise or forward direction.
- The C4 clutch provides engine braking through the 3-4 OWC on overrun.

Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows;

- Solenoids S1 and S2 are switched ON.
- The 1-2, 2-3, and 3-4 shift valves are held in their first gear positions by line 500 pressure.
- Drive (line pressure) oil from the manual valve engages the C2 clutch.
- Lo-1st (line pressure) oil is routed through the 1-2 shift valve to the C4 clutch, and to the inner apply area of the rear servo piston for B2 band application.


Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Manual 1	-	X	-	X	-	X	-	X	-



KAA5A360

5A-26 AUTOMATIC TRANSMISSION

DRIVE 1



Power Flow - Drive 1

In Drive 1, transmission drive is via the input shaft to the forward clutch cylinder. The elements of the transmission function as follows :


- The C2 clutch is engaged to drive the forward sun gear via the 3-4 OWC.
- The forward sun gear drives the short pinion anti-clockwise.
- The short pinion drives the long pinion clockwise.
- The 1-2 OWC prevents the planetary gear carrier from rotating under reaction force and the long pinion rotates on its axis driving the internal ring gear and output shaft in a clockwise or forward direction.
- There is no engine braking on overrun.

Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows:


- Solenoids S1 and S2 are switched ON.
- The 1-2, 2-3, and 3-4 shift valves are held in their first gear positions by line 500 pressure.
- Drive (line pressure) oil from the manual valve engages the C2 clutch.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 1	-	X	-	-	-	-	X	X	-



KAA5A380

DRIVE 2 AND MANUAL 2



Power Flow - Drive 2 and Manual 2

In Drive 2 and Manual 2, transmission drive is via the input shaft and forward clutch cylinder. The elements of the transmission function as follows;

- The C2 clutch is applied to drive the forward sun gear.
- The forward sun gear drives the short pinion anti-clockwise.
- The short pinion drives the long pinion clockwise.
- The B1 band is applied holding the reverse sun gear stationary therefore the long pinion walks around the reverse sun gear taking the internal ring gear and output shaft with it in a clockwise or forward direction.
- The C4 clutch is applied to bypass the 3-4 OWC and provide engine braking on overrun.


Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows;

- Solenoid S1 is switched OFF. S2 is switched ON.


- Drive (line pressure) oil from the manual valve engages the C2 clutch.
- When S1 switches OFF, S1 oil pressure, which is derived from line 500 pressure, moves the 3-4 shift valve to the left. At the same time S1 oil is directed to the 1-2 shift valve which moves the valve to the second gear position.
- 2nd oil (line pressure) from the 1-2 shift valve is directed to the band apply regulator valve, and to the 2-3 shift valve.
- The band apply feed regulator valve supplies 2nd oil (regulated to line pressure multiplied by the valve ratio) to the Band Apply Feed (BAF) circuit.
- Band apply feed oil is directed to;
 - The outer apply area of the front servo
 - The 1-2 shift valve to provide an exhaust port when the transmission is shifted to first gear
 - The 3-4 shift valve for use when the transmission is shifted into fourth gear
- Drive (line pressure) is routed through the 3-4 shift valve to apply the C4 clutch.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 2 and Manual 2	-	X	-	X	X	-	-	X	-



KAA5A400

DRIVE 3 AND MANUAL 3



Power Flow - Drive 3 and Manual 3

In Drive 2 and Manual 2, transmission drive is via the input shaft and forward clutch cylinder. The elements of the transmission function as follows;

- The C2 clutch is engaged to drive the forward sun gear.
- The C1 clutch is engaged to drive the planet carrier.
- The short pinion drives the long pinion clockwise.
- The forward sun gear and the planet carrier are driven clockwise at the same speed therefore there is no relative motion between the sun gear and the pinions.
- The ring gear and output shaft are driven in a clockwise or forward direction at input shaft speed.
- The C4 clutch is applied to bypass the 3-4 OWC and provide engine braking on overrun.


Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows:

- Solenoid S1 is switched OFF. S2 is switched OFF.
- With S1 and S2 switched OFF, the 2-3 and 3-4 shift valves are held in the third gear position by line 500 pressure.
- The 1-2 shift valve is held in the third gear position by S1-S2 oil pressure.
- 2nd oil (line pressure) from the 1-2 shift valve is directed to the band apply feed regulator valve and to the 2-3 shift valve.

- The band apply feed regulator valve supplies 2nd oil (regulated to line pressure multiplied by the valve ratio) to the Band Apply Feed (BAF) circuit.
- Band apply feed oil is directed to;
 - The outer apply area of the front servo
 - The 1-2 shift valve to provide an exhaust port when the transmission is shifted to first gear
 - The 3-4 shift valve for use when the transmission is shifted into fourth gear
- 2nd oil at the 2-3 shift valve is directed to the 3rd oil circuit.
- 3rd oil from the 2-3 shift valve is directed to the clutch apply regulator valve, and to the 4-3 sequence valve.
- The clutch apply regulator valve supplies oil (regulated to line 500 pressure multiplied by the valve ratio) to the Clutch Apply Feed (CAF) circuit. The CAF oil is directed to;
 - The C1clutch
 - The 4-3 sequence valve
- At the 4-3 sequence valve the CAF oil becomes Band 1 Release Feed (B1R-F) oil, and is directed through the 3-4 shift valve to the spring end of the 4-3 sequence valve, and to the release side of the front servo piston to hold band 1 OFF.
- Drive (line pressure) is routed through the 3-4 shift valve to apply the C4 clutch.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 3 and Manual 3	X	X	-	X	-	-	-	X	-



KAA5A420

Power Flow - Drive 3 Lock Up and Manual 3 Lock Up


In Drive 3 Lock Up and Manual 3 Lock Up, transmission drive is the same as for Drive 3 but with the application of the converter lock up clutch to provide positive no-slip converter drive.

Control

Control for Drive 3 Lock Up and Manual 3 Lock Up is the same as for Drive 3 with the addition of the converter clutch circuit activated by solenoid S7.

- When S7 is switched ON, S7 feed oil to the converter clutch control valve is switched OFF and allowed to exhaust through the S7 solenoid. This allows the valve to move to the clutch engage position.
- Regulated apply feed oil, drive oil at the converter clutch regulator valve, is directed by the converter clutch control valve to the engage side of the converter clutch.
- Converter clutch release oil is exhausted at the converter clutch control valve.
- Converter feed oil is re-routed by the converter clutch control valve directly to the oil cooler and lubrication circuit.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 3 Lock Up and Manual 3 Lock Up	X	X	-	X	-	-	-	X	X



KAA5A440

Power Flow - Drive 4 (Overdrive)

In Drive 4 (Overdrive), transmission drive is via the input shaft to the forward clutch cylinder.

The elements of the transmission function as follows;

- The C1 clutch is applied to drive the planet carrier clockwise.
- The B1 band is applied to hold the reverse sun gear stationary.
- As the planet carrier turns, the long pinion walks around the stationary reverse sun gear and rotates around its axis driving the internal ring gear and output shaft in a clockwise or forward direction at a speed faster than the input shaft i.e. in overdrive ratio.
- The forward sun gear is also driven faster than the input shaft and overruns the 3-4 OWC.
- The C2 clutch is engaged to reduce the speed differential across the 3-4 OWC.


Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows;

- Solenoid S1 is switched ON. S2 is switched OFF.
- With S1 switched ON, the 3-4 shift valve is held in the fourth gear position by line 500 pressure on the small end of the valve.
- With S2 switched OFF, the 2-3 shift valve is held in the fourth gear position by line 500 pressure on the large end of the valve.


- The 1-2 shift valve is held in the fourth gear position by S2 oil pressure.
- 2nd oil (line pressure) from the 1-2 shift valve is directed to the band apply feed regulator valve, and to the 2-3 shift valve.
- The band apply feed regulator valve supplies 2nd oil (regulated to line pressure multiplied by the valve ratio) to the Band Apply Feed (BAF) circuit.
- Band apply feed oil is directed to;
 - the outer apply area of the front servo
 - the inner apply area of the front servo piston via the 3-4 shift valve
 - the 1-2 shift valve to provide an exhaust port when the transmission is shifted to first gear
- 2nd oil at the 2-3 shift valve is directed to the 3rd oil circuit.
- 3rd oil from the 2-3 shift valve is directed to the clutch apply regulator valve, and to the 4-3 sequence valve.
- The clutch apply regulator valve supplies oil (regulated to line 500 pressure multiplied by the valve ratio) to the Clutch Apply Feed (CAF) circuit.
- The CAF oil is directed to;
 - the C1 clutch
 - the 4-3 sequence valve
- Drive oil (line pressure) from the manual valve engages the C2 clutch.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 4 Overdrive	X	X	-	-	X	-	-	-	-



KAA5A460

DRIVE 4 LOCK UP



KAA5A47A

Power Flow - Drive 4 Lock Up

In Drive 4 Lock Up, transmission drive is the same as for Drive 4 but with the application of the converter lock up clutch to provide positive no-slip converter drive.


Control

To maintain this arrangement in the steady state solenoids and valves are activated as follows;

- When S7 is switched ON, S7 feed oil to the converter clutch control valve is switched OFF and allowed to exhaust through the S7 solenoid. This allows the valve to move to the clutch engage position.

- Regulated apply feed oil, driven from drive oil at the converter clutch regulator valve, is directed by the converter clutch control valve to the engage side of the converter clutch.
- Converter clutch release oil is exhausted at the converter clutch control valve.
- Converter feed oil is re-routed by the converter clutch control valve directly to the oil cooler and lubrication circuit.

Gear State	ELEMENTS ENGAGED								
	C1	C2	C3	C4	B1	B2	1-2 OWC	3-4 OWC	LU CLUTCH
Drive 4 Lock Up	X	X	-	-	X	-	-	-	-



KAA5A480

DIAGNOSTIC INFORMATION AND PROCEDURES

DIAGNOSIS

BASIC KNOWLEDGE REQUIRED

You must be familiar with some basic electronics to use this section of the Service Manual. They will help you to follow diagnostic procedures.

Notice: Lack of the basic knowledge of this transmission when performing diagnostic procedures could result in incorrect diagnostic performance or damage to transmission components. Do not, under any circumstances, attempt to diagnose a transmission problem without this basic knowledge.

Notice: If a wire is probed with a sharp instrument and not properly sealed afterward, the wire will corrode and an open circuit will result.

Diagnostic test probes are now available that allow you to probe individual wires without leaving the wire open to the environment. These probe devices are inexpensive and easy to install, and they permanently seal the wire from corrosion.

Special Tools

You should be able to use a Digital Volt Meter (DVM), a circuit tester, jumper wires or leads and a line pressure gauge set. The functional check procedure is designed to verify the correct operation of electronic components in the transmission. This will eliminate the unnecessary removal of transmission components.

FUNCTIONAL CHECK PROCEDURE

Begin with the Functional Check Procedure which provides a general outline of how to diagnose automatic transmission. The following functional check procedure will indicate the proper path of diagnosing the transmission by describing the basic checks and then referencing the locations of the specific checks.

- Check the fluid level according to the Fluid Level Service Procedure.
- Check the transmission fluid leak.
- Check if the transmission fluid is not burnt by smell.
Notice: The specific fluid used in this transmission turns brown during normal operation. Brown fluid does not indicate a transmission fault.
- Ensure that the transmission is not in Limp Home Mode (LHM).
- Check the battery terminals and the earth connections for corrosion or looseness.
- Check that the cooler flow is not restricted.
- Check all electrical plug connections for tightness.
- Use on-board diagnostic tool or a scan tool to see if any transmission trouble codes have been set.

Refer to the appropriate "Diagnostic Trouble Code (DTC)" information and repair the vehicle as directed. After repairing the vehicle, perform the road test and verify that the code has not set again.

- Perform the Electrical/Garage Shift Tests.
- Perform the Road Test Procedure in this section.
- Inspect the oil and check for metal or other contaminants in the oil pan.

TRANSMISSION FLUID LEVEL SERVICE PROCEDURE

This procedure is to be used when checking a concern with the fluid level in a vehicle. A low fluid level will result in slipping and loss of drive/ reverse or delay on engagement of drive/ reverse when the vehicle is cold.

The vehicle is first checked for transmission diagnostic messages on the scan tool. If the oil level is low, it is possible to register a vehicle speed signal fault.

The vehicle is to be test driven to determine if there is an abnormal delay when selecting drive or reverse, or loss of drive. One symptom of low fluid level is a momentary loss of drive when driving the vehicle around a corner. Also when the transmission fluid level is low, a loss of drive may occur when the transmission fluid temperature is low.

If there is no loss of drive when the vehicle is driven warm and a vehicle speed signal fault is registered, then fluid should be added to the transmission.

When adding or changing transmission fluid use only Castrol TQ 95 automatic transmission fluid. The use of incorrect fluid will cause the performance and durability of the transmission to be severely degraded.

Fluid Level Diagnosis procedure

1. If the vehicle is at operating temperature allow the vehicle to cool down for two hours, but no greater than four hours. Or if the vehicle is at cool status, start the engine and allow the engine to idle for approximately 5 minutes or, if possible, drive the vehicle for a few kilometers. This will allow the transmission to be within the correct temperature range. Transmission fluid level should be checked at temperature 50 - 60 °C (82 - 140 °F).

Caution: Removal of the fluid filler plug when the transmission fluid is hot may cause injury if fluid drains from the filler hole.

2. With the brake pedal pressed, move the gear shift control lever through the gear ranges, pausing a few seconds in each range. Return the gear shift control lever to P (Park). Turn the engine OFF.

3. Park the vehicle on a hoist, inspection pit or similar raised level surface. The vehicle must be control level to obtain a correct fluid level measurement.
4. Place a fluid container below the fluid filler plug.
5. Clean all dirt from around the fluid filler plug. Remove the fluid filler plug. Clean the filler plug and check that there is no damage to the 'O' ring.
 - If fluid drains through the filler hole the transmission may have been overfilled. When the fluid stops draining the fluid level is correct. Install the fluid filler plug and tighten it to 33 N•m (24 lb-ft).
 - If fluid does not drain through the filler hole, the transmission fluid level may be low. Install the filler pump into the filler hole. Lower the vehicle with the filler pump still connected and partially fill the fluid through the filler hole.
Start the vehicle in P (Park) with the parking brake and the brake applied. With the engine idling, move the gear shift control lever through the gear ranges, pausing a few seconds in each range and adding the fluid until gear application is felt.
Return the gear shift lever to P (Park).
Turn the engine OFF and raise the vehicle. When the three minutes passed after the engine stopped, remove the filler pump.
Check if the fluid level is aligned with the bottom of the filler hole. If not, add a small quantity of fluid to the correct level. Install the fluid filler plug and tighten it to 33 N•m (24 lb-ft).
6. When the fluid level checking procedure is completed, wipe any fluid around the filler plug with a rag or shop towel.

Fluid Level Set After Service

1. Depending on the service procedure performed, add the following amounts of fluid through the filler plug hole prior to adjusting the fluid level:

Converter empty	8.0 liters (8.5 quarts)
Converter full	3.8 liters (4.0 quarts)
2. Follow steps 1 through 4 of the Fluid Level Diagnosis Procedure.
3. Clean all dirt from around the fluid filler plug. Remove the fluid filler plug. Clean the filler plug and check that there is no damage to the 'O' ring.
4. Lower the vehicle with the filler pump still connected and start the vehicle in P (Park) with the parking brake and the brake applied. With the engine idling, move the gear shift control lever through the gear

ranges, pausing a few seconds in each range and adding the fluid until gear application is felt.

Then add an additional 0.5 litres of fluid. Return the gear shift lever to P (Park). Turn the engine OFF and raise the vehicle. Install the fluid filler plug and tighten it to 33 N•m (24 lb-ft).

5. Drive the vehicle at 3.5 to 4.5 kilometers with light throttle so that the engine does not exceed 2500 rpm.
This should result in the transmission temperature being in the range 50 - 60 °C (82 - 140 °F). With the brake applied, move the shift lever through the gear ranges, pausing a few seconds in each range at the engine idling.
6. Return the gear shift lever to P (Park).
Turn the engine OFF and raise the vehicle on the hoist, if applicable, ensuring the vehicle is level. When the three minutes passed after the engine stopped, remove the filler plug.
Check if the fluid level is aligned with the bottom of the filler hole. If not, add a small quantity of fluid to the correct level. Install the fluid filler plug and tighten it to 33 N•m (24 lb-ft).
7. Wipe any fluid around the filler plug with a rag or shop towel.

FLUID LEAK DIAGNOSIS AND REPAIR

The cause of most external leaks can generally be located and repaired with the transmission in the vehicle.

Methods for Locating Leaks

General Method

1. Verify that the leak is transmission fluid.
2. Thoroughly clean the suspected leak area.
3. Drive the vehicle for approximately 25 km (15 miles) or until the transmission reaches normal operating temperature (88 °C, 190 °F).
4. Park the vehicle over clean paper or cardboard.
5. Turn the engine OFF and look for fluid spots on the paper.
6. Make the necessary repairs to correct the leak.

Powder Method

1. Thoroughly clean the suspected leak area.
2. Apply an aerosol type powder (foot powder) to the suspected leak area.
3. Drive the vehicle for approximately 25 km (15 miles) or until the transmission reaches normal operating temperature (88 °C, 190 °F).
4. Turn the engine OFF.
5. Inspect the suspected leak area and trace the leak path through the powder to find the source of the leak.

5A-40 AUTOMATIC TRANSMISSION

6. Make the necessary repairs.

Dye and Black Light Method

1. Add dye to the transmission through the transmission fluid filler plug. Follow the manufacturer's recommendation for the amount of dye to be used.
2. Use the black light to find the fluid leak.
3. Make the necessary repairs.

Repairing the Fluid Leak

Once the leak point is found the source of the leak must be determined. The following list describes the potential causes for the leak:

- Fasteners are not torqued to specification.
- Fastener threads and fastener holes are dirty or corroded.
- Gaskets, seals or sleeves are misaligned, damaged or worn.
- Damaged, warped or scratched seal bore or gasket surface.
- Loose or worn bearing causing excess seal or sleeve wear.
- Case or component porosity.
- Fluid level is too high.
- Plugged vent or damaged vent tube.
- Water or coolant in fluid.
- Fluid drain back holes plugged.

ELECTRICAL / GARAGE SHIFT TEST

This preliminary test should be performed before a hoist or road test to make sure electronic control inputs are connected and operating. If the inputs are not checked before operating the transmission, a simple electrical condition could be misdiagnosed as a major transmission condition.

A scan tool provides valuable information and must be used on the automatic transmission for accurate diagnosis.

1. Move gear shift control lever to P (Park) and set the parking brake.
2. Connect scan tool to Data Link Connector (DLC) terminal.
3. Start engine.
4. Turn the scan tool ON.
5. Verify that the appropriate signals are present. These signals may include:
 - ENGINE SPEED
 - VEHICLE SPEED

- THROTTLE POSITION
- ACCEL. PEDAL POSITION
- TRANSMISSION GEAR STATE
- GEAR SHIFT LEVER POSITION
- TRANSMISSION FLUID TEMPERATURE
- CLOSED THROTTLE POSITION LEARN
- OPEN THROTTLE POSITION LEARN
- CLOSED ACCEL. PEDAL POSITION LEARN
- OPEN ACCEL. PEDAL POSITION LEARN
- A/C COMPRESSOR STATUS
- KICKDOWN SWITCH STATUS
- 4WD STATUS
- MODE SWITCH
- THROTTLE POSITION VOLTAGE
- GEAR SHIFT LEVER POSITION VOLTAGE
- TRANS. FLUID TEMPERATURE VOLTAGE
- A/C SWITCH
- KICKDOWN SWITCH VOLTAGE
- 4WD LAMP LOW VOLTAGE
- 4WD LAMP HIGH VOLTAGE
- MODE SWITCH VOLTAGE
- BATTERY VOLTAGE

6. Monitor the A/C COMPRESSOR STATUS signal while pushing the A/C switch.
 - The A/C COMPRESSOR STATUS should come ON when the A/C switch is pressed, and turn OFF when the A/C switch is repushed.
7. Monitor the GEAR SHIFT LEVER POSITION signal and move the gear shift control lever through all the ranges.
 - Verify that the GEAR SHIFT LEVER POSITION value matches the gear range indicated on the instrument panel or console.
 - Gear selections should be immediate and not harsh.
8. Move gear shift control lever to neutral and monitor the THROTTLE POSITION signal while increasing and decreasing engine speed with the accelerator pedal.
 - THROTTLE POSITION should increase with engine speed.

ROAD TEST PROCEDURE

- Perform the road test using a scan tool.
- This test should be performed when traffic and road conditions permit.
- Observe all traffic regulations.

ELECTRONIC ADJUSTMENTS

Idle Speed Adjustments

Carry out the adjustments to the idle speed as detailed in the workshop manual.

Vehicle Coding

The vehicle coding is integrated as part of the diagnostic software. A scan tool has the function to code the vehicle through the K-line.

Throttle Clearing

The learnt throttle clearing routine uses the mode switch and gear lever. Carry out the following steps to complete the automated throttle clearing procedure:

1. Switch ignition 'ON' with handbrake applied and engine 'OFF'.
2. Select the selector lever to 1st gear and 'WINTER' mode.
3. Move the selector lever to 2nd gear and 'ECONO' or 'POWER' mode.
4. Move the selector lever to 3rd gear and 'WINTER' mode.

Throttle Position Calibration

Should the throttle position data stored in the TCU be lost or be out of specification, as indicated by a diagnostic trouble message, it may be re-established by the following procedure.

- Check that the hot engine idle speed is within specification.
- Allow the engine to idle in 'Drive' for 60 seconds with the air conditioner (if fitted) turned off. The closed throttle reference point in the TCU has now been set.
- Switch the engine off but leave the ignition on. Hold the accelerator pedal on the floor for 60 seconds. The wide open throttle reference point in the TCU has now been set.

SYMPTOM DIAGNOSIS

DRIVE FAULTS

Condition	Possible Causes	Action
No Drive in D	<ul style="list-style-type: none"> • Insufficient auto transmission fluid. • Blocked feed in C1/C2 cylinder. • 'Z' link displaced. • Primary Regulator Valve (PRV) jammed open. • Overdrive shaft or input shaft seal rings failed. • 3-4 or 1-2 One Way Clutch (OWC) installed backwards or failed. • C2 piston broken or cracked. 	<ul style="list-style-type: none"> • Check the fluid level. Top up as necessary. • Inspect and clean C1/C2 feed. • Reinstall/renew the 'z' link. • Remove, clean and re-install the PRV. • Inspect and replace as necessary. • Inspect and replace as necessary. • Inspect and replace as necessary.
No Drive in Reverse No engine braking in Manual 1 Engine braking in Manual 1 is OK	<ul style="list-style-type: none"> • Rear band or servo faulty. • Failure in C3, C3 hub or C1/C2 cylinder. • Damaged input shaft sealing rings. 	<ul style="list-style-type: none"> • Check servo adjustment or replace rear band as necessary. • Check for failure in C3, C3 hub or C1/C2 cylinder. Repair as necessary. • Inspect and replace as necessary.
No drive in Drive and Reverse	<ul style="list-style-type: none"> • Jammed Primary Regulator Valve (PRV). • Damaged/broken pump gears. • Dislodged output shaft snap ring. 	<ul style="list-style-type: none"> • Inspect and clean PRV. • Inspect and replace pump gears as necessary. • Inspect and repair as necessary.

FAULTY SHIFT PATTERN

Condition	Possible Causes	Action
2-3 shift only (no 4th or 1st)	<ul style="list-style-type: none"> S1 always OFF. 	<ul style="list-style-type: none"> Inspect S1. Repair or replace as necessary. Check for 12 Volts applied to S1 at all times or for wiring fault.
1-4 shift only 1-3-4 (Delayed 1-2 shift)	<ul style="list-style-type: none"> S1 always ON. 	<ul style="list-style-type: none"> Inspect S1. Repair or replace as necessary. Check for 12 Volts applied to S1 at all times or for wiring fault.
4-3 shift only	<ul style="list-style-type: none"> S2 always OFF. 	<ul style="list-style-type: none"> Inspect S2. Repair or replace as necessary. Check for open circuit or wiring fault.
1-2-Neutral (1st over run)	<ul style="list-style-type: none"> S2 always ON. 	<ul style="list-style-type: none"> Inspect S2. Repair or replace as necessary. Check for open circuit or wiring fault.
1-3 shift only	<ul style="list-style-type: none"> B1 failed. Loose band adjustment. Front servo piston or seal failed. S1/S2 ball misplaced, 	<ul style="list-style-type: none"> Inspect and repair as necessary. Inspect and adjust as necessary. Inspect and repair as necessary. Inspect and replace or refit as necessary
1-3-4 only	<ul style="list-style-type: none"> Smaller 'O' ring on front servo piston failed or missing. 2-3 shift valve jammed. 	<ul style="list-style-type: none"> Inspect 'O' ring. Refit or replace as necessary. Inspect the 2-3 shift valve. Repair or replace as necessary.
1-2-1 only	<ul style="list-style-type: none"> C1 clutch failed or slipping in 3rd and 4th. (Gives 1st in 3rd and 2nd in 4th.) 	<ul style="list-style-type: none"> Inspect C1 clutch. Repair or replace as necessary.
No manual 4-3, 3-2 or 2-1	<ul style="list-style-type: none"> Over-run Clutch (OC) /low ball misplaced. 	<ul style="list-style-type: none"> Inspect ball. Refit or replace as necessary.
No manual 1st	<ul style="list-style-type: none"> Rear band slipping when hot. Reverse/Low-1st ball misplaced. Rear servo inner 'O' ring missing. 	<ul style="list-style-type: none"> Inspect rear band adjustment. Adjust as necessary. Inspect ball. Refit or replace as necessary. Inspect 'O' ring. Refit or replace as necessary.
1st gear only or 2nd,3rd, and 4th only	<ul style="list-style-type: none"> 1-2 shift valve jammed. 	<ul style="list-style-type: none"> Inspect the 1-2 shift valve. Repair or replace as necessary.
1st and 2nd only or 1st, 3rd and 4th only	<ul style="list-style-type: none"> 2-3 shift valve jammed. 	<ul style="list-style-type: none"> Inspect the 2-3 shift valve. Repair or replace as necessary.
1st, 2nd and 4th only or 1st, 2nd, and 3rd (tied up in 3rd)	<ul style="list-style-type: none"> Inhibitor switch fault, 1-2-3 only. 3-4 shift valve jammed. 	<ul style="list-style-type: none"> Inspect inhibitor switch. Repair or replace as necessary. Inspect the 3-4 shift valve. Repair or replace as necessary.

5A-44 AUTOMATIC TRANSMISSION

Condition	Possible Causes	Action
Harsh 2-3 shift	<ul style="list-style-type: none"> ● Jammed band 1 release valve. ● Faulty S3 or S2 solenoid. ● Faulty clutch apply regulator valve. ● Missing or damaged clutch apply feed ball. ● Damaged input shaft sealing rings. ● Damaged C1 piston 'O' rings. ● Damaged or dislodged C1 piston bleedball. 	<ul style="list-style-type: none"> ● Inspect the release valve. Repair or replace as necessary. ● Inspect S3 or S2. Repair or replace as necessary. ● Inspect the regulator valve. Repair or replace as necessary. ● Inspect the ball. Refit or replace as necessary. ● Inspect the sealing rings. Refit or replace as necessary. ● Inspect the 'O' rings. Refit or replace as necessary. ● Inspect the bleed ball. Refit or replace as necessary.
Harsh 3-4 shift	<ul style="list-style-type: none"> ● Faulty S1 or S4 solenoid. ● Jammed band 1 release valve. ● Incorrect front band adjustment. ● Damaged front servo piston 'O' rings. ● Faulty or damaged variable pressure solenoid (S5). ● Faulty band apply regulator valve. 	<ul style="list-style-type: none"> ● Inspect S1 or S4. Repair or replace as necessary. ● Inspect the release valve. Repair or replace as necessary. ● Inspect the band. Adjust as necessary. ● Inspect the 'O' rings. Refit or replace as necessary. ● Inspect S5. Repair or replace as necessary. ● Inspect the regulator valve. Repair or replace as necessary.

SHIFT QUALITY FAULTS

Condition	Possible Causes	Action
All Shifts Firm	<ul style="list-style-type: none"> • Incorrect auto transmission fluid (ATF). • S5 faulty won, or incorrectly fitted. • Band apply and clutch apply regulator springs misplaced. 	<ul style="list-style-type: none"> • Drain and fill with specified ATF. • Check that S5 is fitted correctly, or replace S5. • Inspect band apply and clutch apply regulator springs. Refit or replace as necessary
Manual 4-3-2-1 is soft delayed or missing	<ul style="list-style-type: none"> • Over-run Clutch (OC) /Low-1st ball misplaced. • C4 clutch worn or burnt. • C4 wave plate not lined up with the holes in the piston. 	<ul style="list-style-type: none"> • Inspect the ball. Refit or replace as necessary. • Inspect C4 clutch. Replace or repair as necessary. • Check the alignment. Realign as necessary.
Firm 1-2 Hot	<ul style="list-style-type: none"> • S5 worn. 	<ul style="list-style-type: none"> • Inspect S5 and replace as necessary.
4th Tied up	<ul style="list-style-type: none"> • Incorrect C4 pack clearance. • Damaged C4 clutch. • Cracked C2 piston (leaking into C4). 	<ul style="list-style-type: none"> • Check the clearance and adjust as necessary. • Inspect C4. Repair or replace as necessary. • Inspect piston. Repair or replace as necessary.
Tied up on 2-3	<ul style="list-style-type: none"> • Incorrect band adjustment • Front servo plastic plug missing • B1R spring broken. 	<ul style="list-style-type: none"> • Inspect and adjust band as necessary. • Replace the plug. • Replace the spring.
Flare on 2-3	<ul style="list-style-type: none"> • B1R spring/plug left out. • C1/B1R ball misplaced. • C1 clutch damaged. • Restriction in C1 feed. • C1 piston check ball jammed. • Overdrive or input shaft sealing rings damaged. 	<ul style="list-style-type: none"> • Replace the spring/plug. • Refit the ball. • Inspect the clutch. Repair the clutch as necessary. • Inspect and clean C1 feed. • Replace the piston. • Inspect and replace the sealing rings and/or shaft as necessary.
Slips in 4th	<ul style="list-style-type: none"> • C1/B1R ball misplaced. • Overdrive or input shaft sealing rings damaged. • C1 clutch damaged. 	<ul style="list-style-type: none"> • Inspect and replace the ball. • Inspect and replace the sealing rings and/or shaft as necessary. • Inspect and repair the C1 clutch as necessary.
Slips in reverse, no manual 1st	<ul style="list-style-type: none"> • Rear band incorrectly adjusted or damage • Low-1st check ball misplaced. 	<ul style="list-style-type: none"> • Inspect and adjust or replace rear band. • Inspect and re-fit the ball.
Flare on 4-3, Flare on 3-2	<ul style="list-style-type: none"> • 4-3 sequence valve in backwards. 	<ul style="list-style-type: none"> • Refit the valve.
Firm Manual low shift-high line press.	<ul style="list-style-type: none"> • Low-1st check ball misplaced. 	<ul style="list-style-type: none"> • Replace the ball.

5A-46 AUTOMATIC TRANSMISSION

Condition	Possible Causes	Action
Harsh 1-2 shift	<ul style="list-style-type: none"> • Faulty inhibitor switch. • Faulty throttle position sensor. • Incorrect front band adjustment. • Damaged front servo piston 'O' rings. • Faulty or damaged variable pressure solenoid (S5). • Faulty S1 or S4 solenoid. • Faulty Band Apply Regulator (BAR) valve. • Misassembled front servo return spring. 	<ul style="list-style-type: none"> • Check the resistance. Replace the inhibitor switch as necessary. • Inspect and replace the sensor as necessary. • Inspect and adjust the band as necessary. • Inspect and replace the 'O' rings as necessary. • Inspect, repair or replace S5 as necessary. • Inspect, repair or replace S1 or S4 as necessary. • Inspect, repair or replace the BAR as necessary. • Inspect and repair as necessary.
Stalls when Drive Or Reverse	<ul style="list-style-type: none"> • Jammed Converter Clutch Control Valve (CCCV). 	<ul style="list-style-type: none"> • Inspect and clean CCCV.
Selected Shudder on Rolldown	<ul style="list-style-type: none"> • Faulty solenoid 7. 	<ul style="list-style-type: none"> • Inspect, repair or replace as necessary.

AFTER TEARDOWN FAULTS

Condition	Possible Causes	Action
C2 burnt	<ul style="list-style-type: none"> • Gear shift lever linkage out of adjustment. • S6 foiled - stuck low. • Overdrive/output shaft sealing rings damaged. • C2 piston cracked. 	<ul style="list-style-type: none"> • Inspect, repair C2 and adjust the linkage as necessary. • Repair C2. Inspect, repair or replace S6 as necessary. • Repair C2. Inspect, replace the sealing rings and/or shaft as necessary. • Repair C2. Inspect, repair or replace the C2 piston as necessary.
C4 burnt	<ul style="list-style-type: none"> • Incorrect C4 pack clearance. • C4 wave plate not lined up properly. • Overdrive or output shaft sealing rings damaged. • C2 piston cracked. • Over-run Clutch (OC) /low-1st ball misplaced. 	<ul style="list-style-type: none"> • Inspect C4 and repair as necessary. • Inspect and adjust the C4 pack clearance as necessary. • Repair C4. Inspect and realign the wave plate as necessary. • Repair C4. Inspect and realign the sealing rings and/or shaft as necessary. • Repair C4. Inspect and replace the C2 piston as necessary. • Repair C4. Inspect and refit the ball as necessary.
B1 burnt	<ul style="list-style-type: none"> • B1R spring broken. • Input shaft sealing ring cut. • C1/B1R ball misplaced. 	<ul style="list-style-type: none"> • Inspect and repair B1 and replace the spring as necessary. • Replace sealing ring. • Repair B1. Refit the ball as necessary.
C1 burnt	<ul style="list-style-type: none"> • B1R spring left out. • Overdrive or input shaft sealing rings damaged. • C1 piston cracked. • Ball capsule jammed. • 4-3 sequence valve in backwards. • Clutch Apply Feed (CAF) /B1R ball left out. 	<ul style="list-style-type: none"> • Inspect and repair C1 and replace the spring. • Repair C1. Inspect and replace the sealing tongs and/or shaft as necessary. • Repair C1. Inspect and replace the C1 piston as necessary. • Repair C1. Inspect and refit the capsule as necessary. • Repair C1. Inspect and refit the valve as necessary. • Repair C1. Inspect and replace the ball as necessary.
B2 burnt (Slips in reverse - no manual 1st)	<ul style="list-style-type: none"> • Rear band incorrectly adjusted or damaged. • Reverse-low/first ball misplaced. 	<ul style="list-style-type: none"> • Inspect and adjust the band as necessary. • Inspect and refit the ball as necessary.

5A-48 AUTOMATIC TRANSMISSION

Condition	Possible Causes	Action
Firm converter lock or unlock	<ul style="list-style-type: none">• Input shaft 'O' ring missing or damaged.• Converter clutch regulator valve in backwards.	<ul style="list-style-type: none">• Inspect and replace the 'O' ring as necessary.• Inspect and refit the valve as necessary.
No lock up at light throttle	<ul style="list-style-type: none">• Input shaft 'O' ring missing or damaged.• C1 bias valve in backwards.	<ul style="list-style-type: none">• Inspect and replace the 'O' ring as necessary.• Inspect and refit the valve as necessary.

BLANK

TROUBLE CODE DIAGNOSIS - GASOLINE VEHICLE

TCM DIAGNOSTIC SYSTEM OVERVIEW

Notice: To prevent Transmission Control Module (TCM) damage. The ignition key must be OFF when disconnection or reconnection the power to the TCM (for example battery cable, TCM pigtail connector, TCM fuse, jumper cables, etc.).

When the TCM detects a system fault, a Diagnostic Trouble Code (DTC) is set in the TCM. This code is present while the fault conditions are met and is stored as a 'History DTC' until cleared. Condition for setting and clearing each TCM DTC are provided in the relevant sections.

In the case where the vehicle type is certified for Euro On-Board Diagnostic (EOBD) compliance, the Engine Control Module (ECM) provides the communication link

to the EOBD scan tool to pass on any EOBD relevant codes from the TCM. The table below contains a list of all supported DTCs and the classification of each for EOBD purposes. Where a type B DTC has been set in an EOBD vehicle, the response to the fault may include action by the ECM, including the illumination of the Malfunction Indicator Lamp (MIL). Refer to *Section 1F, Engine Control*, for details on EOBD system function, checks and fault clearing.

CLEARING TROUBLE CODES

TCM DTCs should be cleared after repairs have been completed. Some diagnostic tables will tell you to clear the codes before using the chart, which will help to find the cause of the problem more quickly. Always note the DTCs present before clearing - this information may be helpful in the diagnostic process."

DIAGNOSTIC TROUBLE CODES

DTC	Description	Type
P0706	Transmission Range Sensor Circuit Range/Performance	B
P0707	Transmission Range Sensor Circuit Low input	B
P0708	Transmission Range Sensor Circuit High input	B
P0710	Transmission Fluid Temperature Sensor Circuit Malfunction	D
P0790	Normal/Performance Switch Circuit Malfunction	D
P1703	Engine Speed Signal Error	D
P1704	Shaft Speed Signal Error	D
P1708	TCM Supply Voltage Low	D
P1709	TCM Supply Voltage High	D
P1712	Kickdown Switch Circuit Malfunction	D
P1713	Pedal Signal Error	D
P1714	EEPROM Vehicle Code Error	D
P1715	VPS Offset Error	D
P1717	RAM Error	D
P1718	ROM Error	D
P1719	CAN Bus Error	D
P1720	EEPROM Error	D
P1721	Throttle Signal Error	D
P1722	Vehicle Type Determination Error	D
P1733	Solenoid 1 Circuit Open	D
P1734	Solenoid 2 Circuit Open	D
P1735	Solenoid 3 Circuit Open	D
P1736	Solenoid 4 Circuit Open	D
P1737	Solenoid 5 Circuit Open	D

DIAGNOSTIC TROUBLE CODES (Cont'd)

DTC	Description	Type
P1738	Solenoid 6 Circuit Open	D
P1739	Solenoid 7 Circuit Open	D
P1741	Solenoid 1 Circuit Short	D
P1742	Solenoid 2 Circuit Short	D
P1743	Solenoid 3 Circuit Short	D
P1744	Solenoid 4 Circuit Short	D
P1745	Solenoid 5 Circuit Short	D
P1746	Solenoid 6 Circuit Short	D
P1747	Solenoid 7 Circuit Short	D

DTC Types

Each DTC is directly related to a diagnostic test. The Diagnostic management system sets DTCs based on the failure of the tests during a driving cycle or cycles. The following are the two types of DTCs and the characteristics of those codes;

Type B

- Emissions related.
- EOBD system "Armed" after one driving cycle with a fail.
- EOBD system "Disarmed" after one driving cycle with a pass.
- Illuminates the MIL on the second consecutive driving cycle with a fail.

- TCM stores a history DTC on the first driving cycle with a fail.
- EOBD system stores a history DTC on the second consecutive driving cycle with a fail, (the DTC will be armed after the first fail).
- EOBD system stores a freeze frame on the second consecutive driving cycle with a fail, (if empty).

Type D

- Non-Emissions related.
- Does not request illumination of any lamp.
- Stores a history DTC on the first driving cycle with a fail.
- EOBD system does not store a freeze frame.

TROUBLE CODE DIAGNOSIS - DIESEL VEHICLE

TCM DIAGNOSTIC SYSTEM OVERVIEW

Notice: To prevent Transmission Control Module (TCM) damage. The ignition key must be OFF when disconnection or reconnection the power to the TCM (for example battery cable, TCM pigtail connector, TCM fuse, jumper cables, etc.).

When the TCM detects a system fault, a Diagnostic Trouble Code (DTC) is set in the TCM. This code is present while the fault conditions are met and is stored

as a 'History DTC' until cleared. Condition for setting and clearing each TCM DTC are provided in the relevant sections.

CLEARING TROUBLE CODES


TCM DTCs should be cleared after repairs have been completed. Some diagnostic tables will tell you to clear the codes before using the chart, which will help to find the cause of the problem more quickly. Always note the DTCs present before clearing - this information may be helpful in the diagnostic process."

DIAGNOSTIC TROUBLE CODES

DTC	Description
P0707	Transmission Range Sensor Circuit Low Input
P0708	Transmission Range Sensor Circuit High Input
P0710	Transmission Fluid Temperature Sensor Circuit Malfunction
P0790	Normal/Performance Switch Circuit Malfunction
P1703	Engine Speed Signal Error
P1704	Shaft Speed Signal Error
P1708	TCM Supply Voltage Low
P1709	TCM Supply Voltage High
P1710	Air Conditioning Switch Circuit Malfunction
P1712	Kickdown Switch Circuit Malfunction
P1714	EEPROM Vehicle Code Error
P1715	VPS Offset Error
P1716	Throttle Not Learnt Error
P1717	RAM Error
P1718	ROM Error
P1720	EEPROM Error
P1721	Throttle Signal Error
P1722	Vehicle Type Determination Error
P1733	Solenoid 1 Circuit Open
P1734	Solenoid 2 Circuit Open
P1735	Solenoid 3 Circuit Open
P1736	Solenoid 4 Circuit Open
P1737	Solenoid 5 Circuit Open
P1738	Solenoid 6 Circuit Open
P1739	Solenoid 7 Circuit Open
P1741	Solenoid 1 Circuit Short
P1742	Solenoid 2 Circuit Short
P1743	Solenoid 3 Circuit Short
P1744	Solenoid 4 Circuit Short

DIAGNOSTIC TROUBLE CODES (Cont'd)

DTC	Description
P1745	Solenoid 5 Circuit Short
P1746	Solenoid 6 Circuit Short
P1747	Solenoid 7 Circuit Short



TCM DIAGNOSTIC SYSTEM CHECK

Circuit Description

The Transmission Control Module (TCM) Diagnostic System Check is the starting point for any driveability complaint diagnosis. Before using this procedure, perform a careful visual/ physical check of the Transmission Control Module (TCM) and the transmission grounds for cleanliness and tightness.

The TCM Diagnostic System Check is an organized approach to identifying a problem created by an electronic transmission control system malfunction.

Diagnostic Aids

An intermittent fault may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for poor connections or a damaged harness. Inspect the TCM harness and connections for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.

TCM Diagnostic System Check

Step	Action	Value(s)	Yes	No
1	1 Turn the ignition OFF. 2. Install the scan tool. 3. Turn the ignition ON, with the engine OFF. 4. Attempt to display the Transmission Control Module (TCM) Data List with the scan tool. Does the scan tool display the TCM data?	-	Go to Step 2	Go to Step 3
2	Select the Trouble Code with the scan tool. Are any Diagnostic Trouble Codes (DTCs) stored?	-	Go to applicable DTC table	System OK, Check Complete

TCM Diagnostic System Check (Cont'd)

Step	Action	Value(s)	Yes	No
3	1. Turn the ignition OFF. 2. Disconnect the TCM connector B. 3. Turn the ignition ON. 4. Check the serial data line from TCM connector terminal A22 to Data Link Connector (DLC) connector terminal 14 for an open, short to ground, or short to voltage. Also, check the DLC ignition feed circuit for an open or short to ground and the DLC ground circuit for an open. Is a problem found?	-	Go to Step 4	Go to Step 5
4	Repair the open, short to ground or short to voltage in the serial data circuit or the DLC ignition feed circuit or the DLC ground circuit. Is a repair complete?	-	Go to Step 1	-
5	Check the TCM ignition feed circuit for an open or short to ground and the TCM ground circuit for an open. Is a problem found?	-	Go to Step 6	Go to Step 7
6	Repair the open or short to ground in the TCM ignition feed circuit or the TCM ground circuit. Is a repair complete?	-	Go to Step 1	-
7	1. Turn the ignition OFF. 2. Disconnect the TCM connector.	-	Go to Step 1	-