

LIFT TECHNOLOGY



GB



Instruction Manual

COMBIVERT F5-Lift

GB

GB-3.....GB-66

1. Introduction.....	4
1.1 Preface.....□	4
1.2 Product description	4
1.3 Safety and Operating Instructions	5
2. Overview of control connections.....	6
2.1 Housing sizes D...E	6
2.2 Housing sizes G...U.....	6
2.3 Motor encoder connection X3A.....	7
2.3.1 Incremental encoder interface	7
2.3.2 SIN/COS encoder interface	7
2.3.3 Resolver encoder interface	7
2.3.4 Hiperface encoder interface.....	8
2.3.5 EnDat encoder interface	8
2.3.6 UVW encoder interface.....	8
2.4 Lift shaft encoder connection X3B	9
2.4.1 Incremental encoder output / incremental encoder input.....	9
2.4.2 SSI encoder interface	9
2.5 Wiring examples / flow charts	10
2.5.1 Connection F5-Lift for binary-coded setpoint selection (factory setting).....	10
2.5.2 Connection F5-Lift for ogive travel with correction input	12
2.5.3 Connection F5-Lift for positioning operation	14
2.6 Control terminal strip X2A	16
2.7 Lift-Operator□	17
2.7.1 Parameterizing interface X6B	17
2.7.2 RS232/485-Interface X6C.....	17
2.7.3 The Operator Panel	18
3. Parameter description	19
3.1 Overview of parameter groups	19
3.2 Basic settings .□	19
3.3 Input of motor data	23
3.4 Adjustment of the motor encoder and shaft encoder	26
3.5 Lift functions ...□	31
3.6 Positioning mode.....	38
3.7 Information, indications and measured values	44
3.8 Adjustment of analog inputs and outputs.....	52
3.9 Adjustment of torque precontrol	56
4 Start-up.....	58
4.1 Start-up of an asynchronous motor without speed encoder with gearbox.	58
4.2 Start-up of an asynchronous motor with speed encoder and gearbox.....	59
4.3 Start-up of a synchronous motor with speed encoder without gearbox	60
5. Error diagnosis	61

1. Introduction

1.1 Preface

We welcome you as a customer of the Karl E. Brinkmann GmbH and congratulate you to the acquisition of this product. You have chosen a product on highest technical standard.

This manual as well as the specified hardware and software are developments of the Karl E. Brinkmann GmbH. Errors and omissions excepted! The Karl E. Brinkmann GmbH have prepared the documentation, hardware and software to the best of their knowledge, however, no guarantee is given that the specifications will provide the efficiency aimed at by the user. The Karl E. Brinkmann GmbH reserves the right to change the specifications without prior notification or further obligation. All rights reserved. The safety and warning instructions specified in this manual do not lay claim on completeness.

The pictograms used in this manual mean:



Danger
Warning
Caution



Attention
observe at
all costs



Information
Help
Tip

1.2 Product description

This instruction manual describes the frequency inverter series KEB COMBIVERT F5 for lift drives. This series convinces through the special adaption of the operation to the requirements of lift drives. The lift functions are available only in connection with the lift operator (part number 00.F5.060-200C).

The power range of KEB COMBIVERT F5 for lift drives ranges from

- 2,2...45 kW / 230 V class
- 2,2...630 kW / 400 V class

The designs are available in following variants:

- heat sink for control cabinet installation (standard)
- heat sink for control cabinet cutout (through-mount version)
- without heat sink for customer-specific cooling systems (Flat-Rear)

1.3 Safety and Operating Instructions



Safety and Operating Instructions for drive converters

(in conformity with the Low-Voltage Directive 73/23/EEG)

1. General

In operation, drive converters, depending on their degree of protection, may have live, uninsulated, and possibly also moving or rotating parts, as well as hot surfaces.

In case of inadmissible removal of the required covers, of improper use, wrong installation or maloperation, there is the danger of serious personal injury and damage to property.

For further information, see documentation.

All operations serving transport, installation and commissioning as well as maintenance are to be carried out by skilled technical personnel (Observe IEC 364 or CENELEC HD 384 or DIN VDE 0100 and IEC 664 or DIN/VDE 0110 and national accident prevention rules!).

For the purposes of these basic safety instructions, „skilled technical personnel“ means persons who are familiar with the installation, mounting, commissioning and operation of the product and have the qualifications needed for the performance of their functions.

Aux Intended use

Drive converters are components designed for inclusion in electrical installations or machinery.

In case of installation in machinery, commissioning of the drive converter (i.e. the starting of normal operation) is prohibited until the machinery has been proved to conform to the provisions of the directive 89/392/EEC (Machinery Safety Directive - MSD). Account is to be taken of EN 60204.

Commissioning (i.e. the starting of normal operation) is admissible only where conformity with the EMC directive (89/336/EEC) has been established.

The drive converters meet the requirements of the Low-Voltage directive 73/23/EEC. They are subject to the harmonized standards of the series DIN EN 50178/ VDE 0160 in conjunction with EN 60439-1/ VDE 0660, part 500, and EN 60146/ VDE 0558.

The technical data as well as information concerning the supply conditions shall be taken from the rating plate and from the documentation and shall be strictly observed.

3. Transport, storage

The instructions for transport, storage and proper use shall be complied with.

The climatic conditions shall be in conformity with EN 50178.

4 Installation

The installation and cooling of the appliances shall be in accordance with the specifications in the pertinent documentation.

The drive converters shall be protected against excessive strains. In particular, no components must

be bent or isolating distances altered in the course of transportation or handling. No contact shall be made with electronic components and contacts.

Drive converters contain electrostatic sensitive components which are liable to damage through improper use. Electric components must not be mechanically damaged or destroyed (potential health risks).

5. Electrical connection

When working on live drive converters, the applicable national accident prevention rules (e.g. VBG 4) must be complied with.

The electrical installation shall be carried out in accordance with the relevant requirements (e.g. cross-sectional areas of conductors, fusing, PE connection). For further information, see documentation.

Instructions for the installation in accordance with EMC requirements, like screening, earthing, location of filters and wiring, are contained in the drive converter documentation. They must always be complied with, also for drive converters bearing a CE marking. Observance of the limit values required by EMC law is the responsibility of the manufacturer of the installation or machine.

6. Operation

Installations which include drive converters shall be equipped with additional control and protective devices in accordance with the relevant applicable safety requirements, e.g. act respecting technical equipment, accident prevention rules etc.. Changes to the drive converters by means of the operating software are admissible.

After disconnection of the drive converter from the voltage supply, live appliance parts and power terminals must not be touched immediately because of possibly energized capacitors. In this respect, the corresponding signs and markings on the drive converter must be respected.

During operation, all covers and doors shall be kept closed.

7. Maintenance and servicing


The manufacturer's documentation shall be followed.

KEEP SAFETY INSTRUCTIONS IN A SAFE PLACE!

2. Overview of control connections

2.1 Housing sizes D...E


Lift operator (00.F5.060-200C)		
HSP5 interface	X6B	
RS232/485 interface	X6D	
Control terminal strip	X2A	
Lift shaft encoding	X3B	
Motor encoder	X3A	




2.2 Housing sizes G...U

Lift operator (00.F5.060-200C)		
HSP5 interface	X6B	
RS232/485 interface	X6D	

Lift shaft encoding	X3B	
Motor encoder	X3A	
Control terminal strip	X2A	



Observe maximum width of the connectors
for X3A and X3B!




2.3 Motor encoder connection X3A

The connection of the motor encoder is done on socket X3A. Which of the encoders can be connected depends on the installed encoder interface and is displayed in LC.11.



All encoder connectors may be connected/disconnected only at switched-off frequency inverter and switched-off supply voltage.



2.3.1 Incremental encoder interface

PIN	Name	Description
3	A-	Differential signal to A+
4	B-	Differential signal to B+
8	A+	Incremental encoder track A
9	B+	Incremental encoder track B
11	+24 V	Voltage output 20...30 V
12	+5 V	Voltage output 5 V, power supply for the encoders
13	COM	Reference potential for voltage supply
14	N-	Differential signal to N+ (if nonexistent, assign with +5 V PIN12)
15	N+	Zero track (if nonexistent, assign with 0 V PIN13)
-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

2.3.2 SIN/COS encoder interface

PIN	Name	Description
1	C-	Differential signal to C+
2	GB -	Differential signal to D+
3	A-	Differential signal to A+
4	B-	Differential signal to B+
6	C+	Absolute track for initial position and angular calculation
7	D+	Absolute track for initial position and angular calculation
8	A+	Incremental signals A for counter and direction detection
9	B+	Incremental signals B for counter and direction detection
12	+5,25 V	Power supply for encoder
13	COM	Reference potential for supply voltage
14	-R	Differential signal to zero track R+
15	+R	Zero track
-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

2.3.3 Resolver encoder interface

PIN	Name	Description
3	SIN-	Negated sinus signal
4	COS-	Negated cosine signal
5	REF-	Negated field voltage output
8	SIN+	Sinus signal
9	COS+	Cosine signal
10	REF+	Field voltage output
14	GND	Connection for shielding of signal lines
-	GND	Connection for shielding of the entire cable at the connector housing. Internally directly connected to the inverter earth.

Description of the unit

2.3.4 Hiperface encoder interface

PIN	Name	Description
3	REF COS	Signal offset to COS
4	REF SIN	Signal offset to SIN
8	COS+	Incremental signal COS for counter and direction detection
9	SIN+	Incremental signal SIN for counter and direction detection
10	+7,5V	Power supply for encoder
13	COM	Reference potential for supply voltage
14	Data-	Data channel RS485
15	Data+	Data channel RS485
-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

2.3.5 EnDat encoder interface

PIN	Name	Description
3	A-	Signal input A- (difference signal to A+)
4	B-	Signal input B- (difference signal to B+)
6	Clock+	Clock signal RS485
7	Clock-	Clock signal RS485
8	A+	Incremental signals A for counter and direction detection
9	B+	Incremental signals B for counter and direction detection
12	+5,25V	Power supply for encoder
13	COM	Reference potential for supply voltage
14	Data-	Data channel RS485
15	Data+	Data channel RS485
-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

2.3.6 UVW encoder interface

PIN	Name	Description
1	U-	Reference point for U+
2	V-	Reference point for V+
3	A-	Differential signal to A+
4	B-	Differential signal to B+
5	W-	Reference point for W+
6	U+	Commutation signal
7	V+	Commutation signal
8	A+	Incremental signal A
9	B+	Incremental signal B
10	W+	Commutation signal
11	+24V	Voltage output 20...30V
12	+5,25V	Power supply for encoder
13	COM	Reference potential for supply voltage
14	N-	Differential signal to zero track N+
15	N+	Zero track
-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

2.4 Lift shaft encoder connection X3B

The connection of the lift shaft encoder is done on socket X3B. Which of the encoders can be connected depends on the installed encoder interface and is displayed in LC.21.



All encoder connectors may be connected/disconnected only at switched-off frequency inverter and switched-off supply voltage.




Figure 1




Figure 2

2.4.1 Incremental encoder output / incremental encoder input

Fig. 1	Fig. 2	Name	Description
1	1	A+	Incremental encoder output /-input track A
2	3	B+	Incremental encoder output /-input track B
3	5	N+	Output / input zero track
4	7	+5 V	Voltage output 5 V, power supply for the encoders
5	-	+24 V	Voltage output 20...30 V
6	2	A-	Differential signal to A+
7	4	B-	Differential signal to B+
8	6	N-	Differential signal to zero track
9	8	COM	Reference potential for voltage supply
-	-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.


2.4.2 SSI encoder interface

Fig. 1	Fig. 2	Name	Description
1	-	CL+	Output of the clock signal
2	-	DAT+	Input data track
3	-	-	-
4	-	+5 V	Voltage output 5 V, power supply for the encoders
5	-	+24 V	Voltage output 20...30 V
6	-	CL-	Differential signal to clock output CL+
7	-	DAT-	Differential signal to data track+
8	-	-	-
9	-	COM	Reference potential for voltage supply
-	-	GND	Connection for shielding at connector housing . Internally directly connected to the inverter earth.

Description of the unit

2.5 Wiring examples / flow charts

2.5.1 Connection F5-Lift for binary-coded setpoint selection (factory setting)




Setpoint selection	Bit 0 (X2A.10)	Bit 1 (X2A.11)	Bit 2 (X2A.12)
0	-	-	-
VR (LF.20)	1	-	-
VL (LF.21)	-	1	-
VN (LF.22)	1	1	-
VI (LF.23)	-	-	1
V1 (LF.24)	1	-	1
V2 (LF.25)	-	1	1
V3 (LF.26)	1	1	1



- To switch the control release a relay (K12) must be used parallel to the safety circuit.
- All 24V-relays triggered by the inverter must be protected with diodes.


Flow chart at factory setting



- t1: The Bit sample for the setpoint values and the direction of travel is set. Immediately after that the inverter the inverter sets the output for the main contactors.
- t2: By a relay parallel to the main contactor control the control release (Start) is set. Thereupon the output phase check is executed.
- t3: Upon successful output phase check the brake output is set. Thereupon the brake opening time runs out. The motor starts to turn.
- t4: The rated speed is reset and switched over to leveling speed.
- t5: The leveling speed is reset and the stopping is initiated.
- t6: On reaching the speed 0 rpm the brake output is reset. Afterwards the brake engage time starts to run.
- t7: The output for the main contactor is reset and thus also the control release and the direction of travel.


Generally the inverter switches the main contactors only in currentless condition.

2.5.2 Connection F5-Lift for ogive travel with correction input




- To switch the control release a relay (K12) must be used parallel to the safety circuit.
- All 24V-relays triggered by the inverter must be protected with diodes.

Flow chart for digital direct approach, peak arch with correction



2.5.3 Connection F5-Lift for positioning operation



- To switch the control release a relay (K12) must be used parallel to the safety circuit.
- All 24V-relays triggered by the inverter must be protected with diodes.

Flow chart for positioning operation, travel from floor 3 to floor 15




Table stopping points

Stopping point	Bit4	Bit3	Bit2	Bit1	Bit0
0 ¹⁾	-	-	-	-	-
1	-	-	-	-	1
2	-	-	-	1	-
3	-	-	-	1	1
4	-	-	1	-	-
5	-	-	1	-	1
6	-	-	1	1	-
7	-	-	1	1	1
8	-	1	-	-	-
⋮	⋮	⋮	⋮	⋮	⋮
30	1	1	1	1	-
31 ²⁾	1	1	1	1	1
¹⁾ only for switch off check at the end of drive					
²⁾ Inspection trip					

Description of the unit

2.6 Control terminal strip X2A





- Tightening torque 0,22...0,25 Nm
- Use shielded / twisted lines
- To avoid interferences a separate shield must be provided for analog and digital control lines as well as the relay outputs
- Apply shield to one side of the inverter to the earth potential.
- The function of the inputs and outputs depends on the operating mode

PIN	Function	Name	Description	Specifications
1	+ Set value input 1	AN1+	Differential voltage input for analog setpoint setting	Input voltage: 0...±10 VDC Ri: 55 kΩ
2	- Setpoint input 1	AN1-		
3	+Pretorque	AN2+	Differential voltage input for analog torque control	
4	-Pretorque	AN2-		
5	Actual speed	ANOUT1	Output of actual speed 0...±10 VDC Δ 0...±maximum speed	Output voltage: 0...±10 VDC Ri: 100 Ω Resolution: ±12 Bit
6	Actual torque display	ANOUT2	Output of actual torque 0...10 VDC Δ 0...maximum torque	
7	+10 V - output	CRF	Reference voltage output for setpoint potentiometer	+10 VDC +5 % max. 4 mA
8	Analog ground	COM	Ground for analog in- and output	13...30 VDC ±0 % smoothed Ri: 2,1 kΩ scan time: 1 ms
9	Analog ground	COM		
10	Progr. input 1	I1	Setpoint Bit 0	
11	Progr. input 2	I2	Setpoint Bit 1	
12	Progr. input 3	I3	Setpoint Bit 2	
13	Progr. input 4	I4	prog. mit Lb.13	
14	Input up/down	F	Input for direction of travel up/down	
15	Progr. input 5	I5	prog. with Lb.11	
16	Control release	ST	Output is enabled, error reset upon release	
17	Progr. input 6	I6	prog. with Lb.12	
18	Transistor output 1	O1	„Ready for operation“; is set if the unit is initialized and no error is present, progr. with LB.16 gesetzt	I _{max} : 50 mA altogether for both outputs
19	Transistor output 2	O2	prog. with Lb.17	
20	24V output	Uout	Supply voltage for digital inputs and outputs	I _{max} : 100 mA
21	20...30V input	Uin	Voltage input for external supply, reference potential 0V	
22	Digital ground	0V	Reference potential for digital inputs/outputs	
23	Digital ground	0V		
24	Relay 1 / NO contact	RLA	Relay output 1, activation of main contactors, progr. with Lb.14	max. 30 VDC 0,01...1A
25	Relay1 / NC contact	RLB		
26	Relay1 / switching contact	RLC		
27	Relay 2 / NO contact	FLA	Relay output 2, brake control, progr. with Lb.15	
28	Relay 2 / NC contact	FLB		
29	Relay 2 / switching contact	FLC		

2.7 Lift-Operator

The F5-Lift operator is integrated into the FI housing by plug-in and fits into all KEB F5 lift units. Parallel to the bus operation over the RS232/485 interface the operation via integrated display/keyboard as well as a further interface for diagnosis/parameterizing (KEB COMBIVIS) is possible.



COM (green)	Interface control ON => Bus operation
E (red)	Operation / Error display ON => inverter ready for operation flashing => inverter in error routine off => no supply voltage
X6B	HSP5 parameterizing interface (COMBIVIS)
X6C	RS232/485 interface
	Reset operator <ul style="list-style-type: none"> in case of abnormal indications which are not described in this instruction manual. disconnect operator briefly from the inverter and reconnect again.


2.7.1 Parameterizing interface X6B



To avoid a destruction of the PC-interface, the diagnostic interface may only be connected via a special HSP5-cable with voltage adaption to a PC!

A HSP5-cable (00.F5.0C0-0001) is connected to the adapter (00.F5.0C0-0002) via the diagnostic interface. The PC-software KEB COMBIVIS 5 now permits normal access to all inverter parameters. The internal operator parameters can also be read and adjusted or parameterized by means of download.

2.7.2 RS232/485-Interface X6C



PIN	RS485	Signal	Meaning
1	-	-	reserved
2	-	TxD	transmission signal RS232
3	-	RxD	receive signal RS232
4	A'	RxD-A	receive signal A RS485
5	B'	RxD-B	receive signal B RS485
6	-	VP	Voltage supply +5V (I _{max} =10 mA)
7	C/C'	DGND	data reference potential
8	A	TxD-A	transmission signal A RS485
9	B	TxD-B	transmission signal B RS485

Description of the unit

2.7.3 The Operator Panel

The function key is used to change between parameter value and parameter number.



With **UP** (▲) and **DOWN** (▼) the parameter number or, in case of changeable parameters, the value is increased/decreased. When holding the key it is automatically switched further.



Principally during a change, parameter values are immediately accepted and stored non-volatile. But at some parameters it is not sensible that the adjusted value is accepted immediately. When this type of parameter is changed, a point appears behind the last digit. The value is stored with ENTER.



If a disturbance occurs during operation, the actual display is overwritten with the error message. The alarm message in the display is reset by ENTER.



With ENTER only the error message is reset. The status display continues to display the error that occurred. In order to reset the error, the cause must be eliminated first. After that the "Reset"-input must be switched or the inverter must be disconnected from the supply.

3. Parameter description

3.1 Overview of parameter groups

The operating menu is divided into following parameter groups:

Gruppe	Name	Function
Lb	Lift basic	Basic setting
Ld	Lift drive	Entry of the motor data
LC	Lift encoder	Adjustment of motor and shaft encoder
LF	Lift Function	Lift-specific adjustments
LP	Lift Posi	Adjustment for positioning operation and ogive run
LI	Lift Info	Information, running messages, measured values, error memory
LA	Lift Analog	Adjustment of analog in- and outputs

The adjustment of the parameters must absolutely be made in ascending order, because:

- the operating menu optimizes itself by displaying only the required parameters.
- the lower parameters effect pre-settings for the following parameters.
- otherwise settings can be overwritten otherwise.

In case of doubt the factory settings should be kept.

3.2 Basic settings

Display	Name	Setting Range	Default setting
Lb.00	Parameter group	BASIC	-
Lb.01	Password	10...65535	11
Lb.02	Customer-specific password	11...65535	11
Lb.03	Drive selection	0...5	2
Lb.04	Positioning mode	0...4	1
Lb.05	Setpoint selection	1...4	1
Lb.06	Reset to factory setting	0...1	0
Lb.07	Pretorque on/off	0...1	0
Lb.10	In-/output configuration	1...2	1
Lb.11	Input function for terminal X2A.15	0...7	1
Lb.12	Input function for terminal X2A.17	0...7	5
Lb.13	Input function for terminal X2A.13	0...7	0
Lb.14	Output function for X2A.24	0...8	1
Lb.15	Output function for X2A.27	0...8	2
Lb.16	Output function for X2A.18	0...8	3
Lb.17	Output function for X2A.19	0...8	7
Lb.18	Brake resistance value	0,5...300,0Ω	30,0Ω

Lb.00 Display of the current parameter group „Basic“

Lb.01 Password

To protect the lift drive against unauthorized access, a password is to be entered before parameterizing. If no password has been set with Lb.02, the factory setting „11“ is valid.

Input	Function
11...65535	Input of password
10	Inhibits the programming
11	Factory setting

Parameter description

Display	Meaning
US_ro	User read-only, programming inhibited, parameter can be read-only
US_on	User on, programming enabled

Lb.02 Customer-specific password

With this parameter a customer-specific password can be defined. It becomes active at the next switch-on and must then be entered before the programming of LB.01.

Input	Function
11...65535	Input of password

Lb.03 Drive selection

With this parameter the main lift drive is defined.

Input	Setting	Motor	Encoder	Gearbox
AELG		Asynchronous motor	none	with
AELGL		Asynchronous motor	none	none
AEG	x	Asynchronous motor	with	with
AEGL		Asynchronous motor	with	none
SEG		Synchronous motor	with	with
SEGL		Synchronous motor	with	none

Lb.04 Positioning mode

Input	Setting	Positioning mode
0		off, conventional lift shaft encoding
1	x	Ogive function
2		Positioning with motor endoder
3		Positioning with absolut value encoder and motor encoder
4		Positioning with absolute value encoder

Lb.05 Setpoint selection

Input	Setting	Setpoint selection	Direction of travel
1	x	binary-coded via terminal X2A.10...12	via terminal strip
2		Input-coded via terminal X2A.10...12	via terminal strip
3		Analog setpoint setting 0...10V	via terminal strip
4		Analog setpoint setting 0...±10V	sign-dependent

Binary-coded setpoint selection

Speed	Bit 0 (terminal X2A.10)	Bit 1 (terminal X2A.11)	Bit 2 (terminal X2A.12)
0	-	-	-
VR (LF.20)	1	-	-
VL (LF.21)	-	1	-
VN (LF.22)	1	1	-
VI (LF.23)	-	-	1
V1 (LF.24)	1	-	1
V2 (LF.25)	-	1	1
V3 (LF.26)	1	1	1

Input-coded setpoint selection

Speed	Terminal X2A.10	Terminal X2A.11	Terminal X2A.12	Terminal X2A.13
0	-	-	-	-
VL (LF.21)	1	-	-	-
VN (LF.22)	-	1	-	-
VI (LF.23)	-	-	1	-
V1 (LF.24)	-	-	-	1

Analog setpoint setting

The analog setpoint setting is done over terminals X2A.1 and X2A.2. The speed is calculated according to following formula:

value „3“ 0...10 V correspond to 0...maximum lift speed (LF.01)

value „4“ 0...±10 V correspond to 0...±maximum lift speed (LF.01)

If the drive profile is generated with the setpoint value, the values LF.30...LF.36 must be set to „off“.

Lb.06 Reset to factory setting

Input	Setting	Description
0	x	-
1		By setting '1' and press 'ENTER' and power-on the factory setting is reset.

Lb.07 Pretorque

Input	Setting	Pretorque	Description
0	x	off	Is adjusted for drives with gearboxes.
1		on	Analog signal at the terminals X2A.3 and X2A.4 is used for the torque precontrol with gearless drives.

Adjustment of amplification and offset see parameters LA.12 / LA.14.

Lb.10 In-/ Output configuration

With this parameter the programming of the digital inputs (Lb.11...13) and the digital outputs (Lb.14...17) can be enabled. The programming is generally inhibited for positioning operation (Lb.01 = 2...4).

Input	Setting	Programming	Description
1	x	inhibited	The configuration of the in- and outputs is reset to factory setting.
2		enabled	The programming of the in- and outputs with the parameters Lb.11...17 is enabled.

Parameter description

Lb.11 Input function for terminal X2A.15

Lb.12 Input function for terminal X2A.17

Lb.13 Input function for terminal X2A.13

Input	Setting	Function	Description
0		off	
1	X2A.15	Direction of rotation reverse	
2	X2A.13	Contactor control	
3		Quick stopping	
4		Control mode	
5	X2A.17	UPS-operation	
6		Safety-gear release	
7		Brake switching surveillance	
8		Contactor control and brake switching surveillance	
9		Correction input	

Lb.14 Output function for X2A.24...26 (relay output 1)

Lb.15 Output function for X2A.27...29 (relay output 2)

Lb.16 Output function for X2A.18 (transistor output 1)

Lb.17 Output function for X2A.19 (transistor output 2)

Input	Setting	Function	Description
0		off	
1	X2A.24	Main contactor activation	
2	X2A.27	Brake handling with phase check	
3	X2A.18	Ready for operation and overspeed	
4		Motor or inverter temperature warning	
5		Activation control cabinet fan	
6		Speed for deceleration check	
7	X2A.19	Speed for running open doors	
8		Speed deviation warning	

Lb.18 Brake resistance value

Value range	Setting	Description
0,5...300,0 Ω	30,0 Ω	Input of the actually used brake resistance value. With it the inverter calculates the refed energy and outputs the result in parameter LI.23. It serves as decision support on whether the employment of a feedback unit would be worth it.

3.3 Input of motor data

Display	Name	Setting Range	Default setting
Ld.00	Parameter group	drluE	-
Ld.01	Power rating	0,0...315,0 kW	4,0 kW
Ld.02	Rated speed	0,00...4000,00 rpm	1500,00 rpm
Ld.03	Rated current	0,0...1000,0A	-
Ld.04	Rated frequency	0,0...800,0 Hz	50,0 Hz
Ld.05	cos phi	0,00...1,00	-
Ld.06	Rated voltage	0...1000 V	400 V
Ld.07	Winding resistance measure	0...1	0
Ld.08	Winding resistance	0,000...50,000 Ω	49,999 Ω
Ld.09	Winding inductivity	0,00...500,00 mH	-
Ld.10	Rated torque	unit-dependent	auto
Ld.11	Maximum inverter torque	unit-dependent	auto
Ld.12	Maximum torque limitation	unit-dependent	0,95 • Ld.11
Ld.13	Field weakening speed	0,00...10000,00 rpm	auto
Ld.14	Current limit	0,0...100,0 %	100,0 %
Ld.20	Maximum torque at UPS-operation	unit-dependent	auto
Ld.21	Current limit at UPS-operation	0,0...100,00 %	100,0 %
Ld.22	- only for internal use -	-	-
Ld.23	- only for internal use -	-	-

Ld.00 Display of current parameter group „drive“

Drive-specific data are entered in this parameter group. Depending on the adjusted drive type (Lb.03) only certain data are required.

Ld.01 Power rating

Value range	Setting	Description
0,0...315,0 kW	4,0 kW	Input of the motor power rating according to motor name plate. Only display at synchronous motors.

Ld.02 Rated speed

Value range	Setting	Description
0,00...xx,00 min ⁻¹	1450 rpm	Input of the motor rated speed according to motor name plate.

Ld.03 Rated current

Value range	Setting	Description
0,0...1000,0A	-	Input of the motor rated current according to motor name plate.

Ld.04 Motor rated frequency

Value range	Setting	Description
0,0...315,0 Hz	50,0 Hz	<p>Input of the motor rated frequency according to motor name plate. For synchronous motors frequency and speed depend on each other according to following formula.</p> $\text{Motor speed} = \frac{\text{Frequency} \cdot 60}{\text{Pole-pair number}}$ <p>The pole-pair number is always a whole-numbered value!</p>

Parameter description

Ld.05 Cos phi

Value range	Setting	Description
0,0...1,0	-	Input of the cos phi of the motor according to motor name plate.

Ld.06 Rated voltage

Value range	Setting	Description
0,0...1000 V	400 V	Input of the motor rated voltage according to motor name plate.

Ld.07 Calibration of winding resistance (only at Lb.03 = 0 or 1)

Value range	Setting	Description
0	x	Basic position before and after the automatic calibration.
1		<ul style="list-style-type: none"> Bring motor to working temperature Activate calibration mode by setting „1“ Set drive command (e.g. return) Set control release Press UP (▲) -key in Ld.08 The calibration starts and is completed after approx. 10 s Ld.08 displays now the measured value Cancel the drive command Open control release, thereby the measure procedure is finished

Ld.08 Winding resistance

Value range	Setting	Description
0,00...50,00 Ω	49,99 Ω	<p>With this parameter the direct input of the motor winding resistance can be made.</p> <p>Measure with a multimeter: The motor resistance is measured, independent of the motor connection (Δ/Y), between two phases of the motor feed line. That way the ohmic line resistance is recorded at the same time (important in case of long feed lines). At that the motor should be at working temperature.</p> <p>Input of the motor winding resistance according to data sheet: When taking the motor resistance from a data sheet, the R120 - equivalent resistance (phase value) is mostly specified there. Then the following values, depending on the used connection, must be adjusted in Ld.08 : Star connection: $Ld.08 = 2 \cdot R120$ to $2,24 \cdot R120$ Delta connection: $Ld.08 = 0,666 \cdot R120$ to $0,75 \cdot R120$ If only the warm resistance R1W is specified: Star connection: $Ld.08 = 1,4 \cdot R1w$ to $1,6 \cdot R1w$ Delta connection: $Ld.08 = 0,46 \cdot R1w$ to $0,53 \cdot R1w$</p>

Ld.09 Wicklungsinduktivität

Value range	Setting	Description
0,00...500,00 mH	x,x mH	<p>Input of the leakage inductivity of the motor winding.</p> <p>When taking the leakage inductivity from a data sheet, the phase value for σLS is mostly specified there. Then the following value, depending on the used connection, must be entered in Ld.09: Star connection: $Ld.09 = 2 \times \sigma LS$ Delta connection: $Ld.09 = 2/3 \times \sigma LS$</p>

Ld.10 Rated torque

Value range	Setting	Description
0,0...xxx,0 Nm	xx Nm	Input of the motor rated torque according to the data sheet.

Ld.11 Maximum torque of inverter

Value range	Setting	Description
0,0...xxxx Nm	Nm	Based on the peak current of the inverter, the maximum torque that can be supplied by the inverter, is displayed.

Ld.12 Maximum torque limitation

Value range	Setting	Description
0,0...xxxx Nm	$0,95 \cdot \text{Ld.11}$	Adjustment of the maximum torque limit.

Ld.13 Field weakening speed

Value range	Setting	Description
0,0...10000,0 min ⁻¹	auto	Input of the field weakening speed according to the data sheet.

Ld.14 Current limit (at Lb.03 = AELG)

Value range	Setting	Description
0,0...100,0 %	100,0 %	Adjustment of the upper current limitation in percent relating to the inverter rated current..

Ld.20 Maximum torque for UPS-operation

Value range	Setting	Description
0,0...xxx,0 Nm	xxx,0 Nm	Adjustment of the maximum torque limit during UPS-operation. The value becomes active, if an input programmed for it is set.

Ld.21 Current limit at USV operation (at Lb.03 = AELG)

Value range	Setting	Description
0,0...100,0 %	100,0 %	Adjustment of the upper current limitation in percent relating to the inverter rated current during UPS-operation. The value becomes active, if an input programmed for it is set.

Ld.22 Do not change - only for internal use!

Ld.23 Do not change - only for internal use!

Parameter description

3.4 Adjustmetn of the speed encoder

Display	Name	Setting Range	Default setting
LC.00	Parameter group	Enc	-
LC.01	Selection motor encoder input	0...1	0
LC.02	Encoder 1 Status	-	-
LC.11	Display Interface 1	-	-
LC.12	Increments Encoder 1	0...65535 Ink	2500 Ink
LC.13	Track change and travel direction inverting Encoder 1	0...17	0
LC.14	Encoder pole-pair	0...xx	1
LC.15	Teach-in system position	0...7	-
LC.16	System position value	0...65535	-
LC.17	Filter time for actual speed Encoder 1	0...5	3
LC.21	Display Interface 2	-	-
LC.22	Increments Encoder 2	0...65535	4096
LC.23	Track change and travel direction inverting Encoder 2	0...17	0
LC.27	Filter time for actual speed Encoder 2	0...5	3
LC.30	Encoder 1 type	0...64	-
LC.31	Encoder 1 read/write data	0...1	-
LC.40	SSI Multiturn-resolution	0...12 Bit	12 Bit
LC.41	SSI clock frequency	0...1	1
LC.42	SSI data format	0...1	0
LC.43	SSI voltage surveillance	0...1	0

LC.00 Parameter group

The LC parameters (Lift Encoder) include all parameters for the adjustment of the encoder and the encoder interfaces.

LC.01 Selection motor encoder input

Input	Setting	Description
0	x	Motor speed encoder is connected to input X3A.
1		Motor speed encoder is connected to input X3B .

LC.02 Encoder 1 Status

This parameter shows the status of intelligent encoders (Hiperface, ENDAT, SIN/COS) and the encoder interface 1. Depending on the encoder only certain messages are possible. An error is triggered only upon control reset, even though it is already displayed in LC.02.

Inverter status	Value	Description
no error	16	System position values are transferred, encoder and interface are all right.
Error „E.EncC“		The correct evaluation of the system position is no longer ensured. The error E.EncC can only be reset via parameter Ec.0. Exception! An error, due to wrong encoder increments (value 70), is immediately reset, once the correct encoder increments are adjusted. Attention, if the control release is still set, the modulation is enabled!
	64	Encoder unknown and not supported.
	68	No encoder connected or encoder breakage detection has tripped.
	69	System deviation too large. The position, determined from the incremental signals, and the absolute position (from absolute track, zero signal or serial read) no longer match or cannot be corrected.
	70	Adjusted increments do not match the encoder increments.
	71	Interface type is unknown: Interface was not identified.
	75	Encoder temperature is too high (message from encoder)
	76	Speed is too high (message from encoder)
	77	Encoder signals are outside the specifications (message from encoder)
	78	Encoder has an internal defect (message from encoder)
	92	Encoder is formatted. When writing on an encoder, whose storage structure does not correspond to the KEB definition, the storage areas are reorganized, so that they can be written on. Depending on the storage structure, this process can take several seconds.
Error „E.Enc1“	96	New value recognized, because another encoder was plugged in.
	98	Interface is busy.
Error „E.Hyb“		During read out of the encoder the error „E.Enc1“ is output.
	97	KEB identifier undefined. Storage structure of the encoder does not correspond to the KEB definition, thus data cannot be read. By writing on it the encoder is defined. The error can be reset as follows: • Writing a system position into Ec.2. • Carry out a system position alignment .
	0 255	No communication between interface and control board

LC.11 Display Interface 1

Shows which encoder interface is installed and thus which encoder may be connected to channel 1 (X3A).

Value	Installed encoder interface
0	none
1	Incremental encoder input TTL
2	Incremental encoder output 5V
3	Incremental encoder in- and output direct
4	Incremental encoder in- and output TTL
5	Initiator
6	Synchron-serial interface (SSI)
7	Resolver
8	Tacho
9	Incremental encoder output TTL of resolver via channel 2
10	Incremental encoder output TTL

continued on next page

Parameter description

Value	Installed encoder interface
11	Hiperface
12	Incremental encoder input 24 V HTL
13	Incremental encoder input TTL with error detection
14	SIN/COS
15	Incremental encoder input 24 V HTL with error detection (push-pull)
16	ENDAT
17	Incremental encoder input 24 V HTL with error detection
18	Analog option ± 10 V

In case of an invalid encoder identifier the error „E.Hyb“ is displayed and the measured value is indicated negated. When changing the encoder interface the error „E.HybC“ is displayed. By writing on this parameter the change is confirmed and the default values for the new interface are loaded.

LC.12 Increment Encoder 1

Value range	Setting	Description
0...65535 Ink	2500 Ink	Input of the encoder increments (number of increments per revolution).

LC.13 Track change and travel direction inverting Encoder 1

With this parameter the encoder tracks A and B on the encoder interface X3A can be exchanged. In addition to that the travel direction inverting can be activated. Thus it is possible to run the motor with positive setting counter-clockwise on the shaft without changing the hardware.

Input	Setting	Change Encoder tracks A/B	Travel direction inverting
0	x	-	-
1		YES	-
16		-	YES
17		YES	YES

LC.14 Encoder pole-pairs

Value range	Setting	Description
0...xxx	1	Adjustment of the encoder pole-pairs for encoders with several commutation signals.

LC.15 Determine system position (only for synchronous motors)

If the drive system (inverter and motor) is started for the first time, the system position of the encoder to the rotor position of the motor must be known. By entering „1“ in LC.15 the system position alignment is started. In doing so the drive may not be loaded (remove cable from the leading sheave). After the system position alignment is completed, the determined value is displayed in LC.16.

During the alignment several functional steps are carried out which are displayed as feedback signals.

Value	Action inverter	Action operator
0	No system alignment carried out	-
1	-	Enter „1“, set drive command
2	Calibration procedure	-
3	Procedure completed	Cancel the drive command

LC.16 System position value

Value range	Setting	Description
0...65535	-	In this parameter the position of the encoder to the rotor position of the motor is displayed (also see LC.15). If the system position of motor and rotor is known, then the position alignment described under LC.15 needs not to be made. The position value can be entered directly into the parameter. The value is stored with „ENTER“.

LC.17 Filter time Encoder 1

Value range	Setting	Description					
0...5	3	Serves for the smoothing of faulty speed signals.					
		0 = 0,5 ms	1 = 1 ms	2 = 2 ms	3 = 4 ms	4 = 8 ms	5 = 16 ms

LC.21 Display Interface 2

Indicates which encoder interface is installed and thus which encoder may be connected to channel 2 (X3B).

Value	Installed encoder interface
0	none
1	Incremental encoder input TTL
2	Incremental encoder output 5 V
3	Incremental encoder in- and output direct
4	Incremental encoder in- and output TTL
5	Initiator
6	Synchron-serial interface (SSI)
7	Resolver
8	Tacho
9	Incremental encoder output TTL of resolver via channel 2
10	Incremental encoder output TTL
11	Hiperface
12	Incremental encoder input 24 V HTL
13	Incremental encoder input TTL with error detection
14	SIN/COS
15	Incremental encoder input 24 V HTL with error detection (push-pull)
16	ENDAT
17	Incremental encoder input 24 V HTL with error detection
18	Analog option ± 10 V

In case of an invalid encoder identifier the error „E.Hyb“ is displayed and the measured value is indicated negated. When changing the encoder interface the error „E.HybC“ is displayed. By writing on this parameter the change is confirmed and the default values for the new interface are loaded.

LC.22 Increments Encoder 2

Value range	Setting	Description
0...65535 Ink	4096 Ink	Input of the encoder increments (number of increments per revolution).

LC.23 Track change and travel direction inverting Encoder 2

With this parameter the encoder tracks A and B on the encoder interface X3B can be exchanged. In addition to that the travel direction inverting can be activated. Thus it is possible to run the motor with positive setting counter-clockwise on the shaft without changing the hardware.

Input	Setting	Change Encoder tracks A/B	Travel direction inverting
0	x	-	-
1		YES	-
16		-	YES
17		YES	YES

Parameter description

LC.27 Filter time Encoder 2

Value range	Setting	Description						
0...5	3	Serves for the smoothing of faulty speed signals. <table><tr><td>0 = 0,5ms</td><td>1 = 1 ms</td><td>2 = 2 ms</td><td>3 = 4 ms</td><td>4 = 8 ms</td><td>5 = 16 ms</td></tr></table>	0 = 0,5ms	1 = 1 ms	2 = 2 ms	3 = 4 ms	4 = 8 ms	5 = 16 ms
0 = 0,5ms	1 = 1 ms	2 = 2 ms	3 = 4 ms	4 = 8 ms	5 = 16 ms			

LC.30 Encoder 1 Type

Display	Description
0	no encoder identified
2	SCS 60/70
7	SCM 60/70
34	SRS 50/60
39	SRM 50/60
64	undefined type

LC.31 Encoder 1 read/write data

Input	Setting	Description
0		
1		

LC.40 SSI Multiturn-resolution

Input	Setting	Description
0...12 Bit	12 Bit	Number of Bits for the multiturn-resolution, if a SSI multiturn-absolute value encoder is connected.

LC.41 SSI Clock frequency

Adjustment of the clock frequency for SSI-encoder.

Input	Setting	Description
0		156,25 kHz, if interferences occur due to long encoder lines
1	x	312,5 kHz

LC.42 SSI Data format

Input	Setting	Description
0	x	Binary-coded
1		Graycode

LC.43 SSI Voltage monitoring

Input	Setting	Description
0	x	
1		

3.5 Lift functions

Display	Name	Setting Range	Default setting
LF.00	Parameter group	LIFt	-
LF.01	max. speed of system	0,000...15,000 m/s	0,000 m/s
LF.02	Traction sheave diameter	0...2000 mm	600 mm
LF.03	Gear reduction ratio multiplier	0,00...99,99	30,00
LF.04	Gear reduction ratio divisor		
LF.05	Factor rope suspension	1...8	1
LF.06	Contract load	0...65535 kg	0 kg
LF.10	Control mode	0...2	2
LF.11	KP speed controller	0...65535	auto
LF.12	KI speed controller	0...65535	auto
LF.13	KI speed controller Offset	0...65535	auto
LF.14	KP current controller	0...65535	auto
LF.15	KI current controller	0...65535	auto
LF.16	Boost	0,0...25,5 %	10,0 %
LF.17	Autoboost on/off	0...1	auto
LF.18	Autoboost / amplification	0,00...2,55	1,20
LF.20	VR releveling speed	0,000...0,300 m/s	0,000 m/s
LF.21	VL leveling speed	0,000...0,300 m/s	0,000 m/s
LF.22	VN nominal speed	0,000 m/s...LF.01	0,000 m/s
LF.23	Vi inspection speed	0,000...0,630 m/s	0,000 m/s
LF.24	V1 first intermediate speed	0,000 m/s...LF.01	0,000 m/s
LF.25	V2 second intermediate speed	0,000 m/s...LF.01	0,000 m/s
LF.26	V3 third intermediate speed	0,000 m/s...LF.01	0,000 m/s
LF.27	Vu evacuation speed	0,000 m/s...LF.01	0,000 m/s
LF.28	Set value debounce time	0...127 m/s	0 m/s
LF.30	Starting jerk	0,01...9,99 m/s ³	0,50 m/s ³
LF.31	Acceleration	0,01...2,00 m/s ²	0,90 m/s ²
LF.32	Jerk at end of acceleration	0,01...9,99 m/s ³	1,00 m/s ³
LF.33	Jerk at begin of deceleration	0,01...9,99 m/s ³	1,00 m/s ³
LF.34	Deceleration	0,01...2,00 m/s ²	0,90 m/s ²
LF.35	Jerk at end of deceleration	0,01...9,99 m/s ³	1,00 m/s ³
LF.36	Stopping jerk	0,01...9,99 m/s ³	0,50 m/s ³
LF.40	Brake release time	0,00...3,00 s	0,30 s
LF.41	Brake engage time	0,00...3,00 s	0,30 s
LF.42	Switching threshold brake deactivation	0,000...0,010 m/s	0,005 m/s
LF.43	Level overspeed	0,000...18,000 m/s	1,1•LF.1
LF.44	Deceleration check	0,000...15,000 m/s	0,95•LF.1
LF.45	Level „running open doors“	0,000...0,300 m/s	0,250 m/s
LF.46	Speed deviation mode	0...1	0
LF.47	Speed deviation level	0...30 %	10 %
LF.48	Speed deviation tripping time	0,000...10,000 s	3,000 s
LF.49	Motor + inverter OH-function	0...1	0
LF.50	drive OH delay time	0...3600 s	0 s
LF.60	Display levelling distance	0,0...264,0 cm	-
LF.61	Levelling way optimization VN	0,0...200,0 cm	0,0 cm
LF.62	Levelling way optimization V1	0,0...200,0 cm	0,0 cm
LF.63	Levelling way optimization V2	0,0...200,0 cm	0,0 cm
LF.64	Levelling way optimization V3	0,0...200,0 cm	0,0 cm

Parameter description

LF.00 Display of current parameter group „LIFt“

LF.01 Max. speed of system

This parameter limits the speed of the system to the adjusted value. For analog setpoint setting applies 0...±10V correspond to 0...±LF.01.

Value range	Setting	Description
0,000...15000 m/s	0,000 m/s	

LF.02 Traction sheave diameter

Value range	Setting	Description
0...2000 mm	600 mm	Enter the diameter of the traction sheave.

LF.03 Gear reduction ratio/multiplier

Value range	Setting	Description
0,00...99,99	30,00	Adjustment according to gearbox name plate (possible determination by counting the revolutions of the handwheel at one revolution of the traction sheave). Example: $i = 43:3$ LF.3=43 For gearless motors adjust value „1“.

LF.04 Gear reduction ratio/divisor

Value range	Setting	Description
0,00...99,99	1,00	Adjustment according to gearbox name plate (possible determination by counting the revolutions of the handwheel at one revolution of the traction sheave). Example: $i = 43:3$ LF.4=3 For gearless motors adjust value „1“.

LF.05 Factor rope suspension

Value range	Setting	Description
1...8	1	Adjustment according to system data (1:1...8:1)

LF.06 Additional load

Value range	Setting	Description
0...65535 kg	0	Adjustment according to system data (possibly number of persons x 75 kg)

LF.10 Control mode

Value range	Setting	Description
0		Without speed encoder (open-loop)
1		Control mode switchable by digital input
2	x	With speed encoder (closed-loop)

LF.11 KP Speed controller

Value range	Setting	Description
0...65535	auto	Adjustment of the P-amplification of the speed controller. If the KP-values are too large vibrations occur during the constant drive. If the KP-values are too small a deviation between setpoint and actual value occurs. It results in transient effects after the acceleration.

LF.12 KI Speed controller

Value range	Setting	Description
0...65535	auto	Adjustment of the I-amplification of the speed controller.

LF.13 KI Speed controller Offset

Value range	Setting	Description
0...65535	auto	Serves for an improved load transfer at high-efficient gearboxes and pm-gearless-motors.

LF.14 KP Current controller

Value range	Setting	Description
0...65535	auto	P-amplification of the magnetizing and active current.

LF.15 KI Current controller

Value range	Setting	Description
0...65535	auto	I-amplification of the current controller.

LF.16 Boost/ torque increasing

Value range	Setting	Description
0,0...25,5 %	auto	Serves for the adjustment of the U/f-characteristic in open-loop operation. Too little torque increase makes the motor soft and the load cannot be lifted. Too much torque increase leads to vibration during acceleration and in the positioning drive.

LF.17 Autoboot on/off

Value range	Setting	Description
0	auto	Autoboot (torque compensation) off
1		Autoboot is effective in the motor-driven and generatoric operation (recommend for old lift motors).

LF.18 Autoboot / amplification

Value range	Setting	Description
0,00...2,55	1,20	Adjustment of the amplification factor for Autoboot.

LF.20 VR Releveling speed

Value range	Setting	Description
0,000...0,300 m/s	0,000 m/s	With the releveling speed the lift is driven back to the floor level. <ul style="list-style-type: none"> • for a better positioning the drive abort is made without jerk limitation • it cannot be accelerated from the releveling speed • not active at Lb.05 = 2

LF.21 VL Leveling speed

Value range	Setting	Description
0,000...0,300 m/s	0,000 m/s	• it cannot be accelerated from the leveling speed

LF.22 Vn Nominal speed

Value range	Setting	Description
0,000 m/s...LF.01	0,000	

Parameter description

LF.23 V_I Inspection speed

Value range	Setting	Description
0,000...0,630 m/s	0,000 m/s	• it cannot be accelerated from the inspection speed

LF.24 V₁ First intermediate speed

Value range	Setting	Description
0,000 m/s...LF.01	0,000 m/s	• not active at Lb.05 = 2

LF.25 V₂ Second intermediate speed

Value range	Setting	Description
0,000 m/s...LF.01	0,000 m/s	• not active at Lb.05 = 2

LF.26 V₃ Third intermediate speed

Value range	Setting	Description
0,000 m/s...LF.01	0,000 m/s	• not active at Lb.05 = 2

LF.27 V_U Evacuation speed in UPS-run

Value range	Setting	Description
0,000 m/s...LF.01	0,000 m/s	• off, if no input is assigned with the function „UPS-operation“

LF.28 Set value debounce time

Value range	Setting	Description
0...127 ms	0 m/s	

LF.30 Starting jerk

Important for the well-being of passengers in a lift is the so-called jerk or shock, that always occurs during acceleration processes. This phenomenon even causes objects on conveyor system to topple or fall and puts a heavy strain on mechanical components. People perceive the jerk differently, depending on age, physical and mental constitution and whether the movement was anticipated or not.

Value range	Setting	Description
0,01...9,99 m/s ³	0,50 m/s ³	Experience values: 0,5...0,8 m/s ³ for nursing homes, hospitals, apartment houses 0,8...1,2 m/s ³ for office buildings, banks etc.

LF.31 Acceleration

Value range	Setting	Description
0,01...2,00 m/s ²	0,90 m/s ²	Experience values: 0,5...0,8 m/s ² for nursing homes, hospitals, apartment houses 0,8...1,2 m/s ² for office buildings, banks etc.

LF.32 Jerk at end of acceleration

Value range	Setting	Description
0,01...9,99 m/s ³	1,00 m/s ³	If the jerk at the end of acceleration is adjusted too low, the parameter „deceleration“ LF.34 is overridden.

LF.33 Jerk at begin of deceleration

Value range	Setting	Description
0,01...9,99 m/s ³	1,00 m/s ³	

LF.34 Deceleration


Value range	Setting	Description
0,01...2,00 m/s ²	0,90 m/s ²	

LF.35 Jerk at end of deceleration

Value range	Setting	Description
0,01...9,99 m/s ³	0,70 m/s ³	

LF.36 Stopping jerk

Value range	Setting	Description
0,00...9,99 m/s ³	0,40 m/s ³	The stopping jerk determines the ride comfort between leveling speed and stopping at the floor level. With LF.36="off" the stopping jerk is the same as the jerk at the end of deceleration (LF.35).



Driving characteristic with acceleration, deceleration and limited jerks

LF.40 Brake release time

Value range	Setting	Description
0,00...3,00 s	0,30 s	When the time is too short you may feel a jerk whilst starting.

LF.41 Brake engage time

Value range	Setting	Description
0,00...3,00 s	0,30 s	When the time is too short you may feel roll-back whilst stopping.

LF.42 Switching threshold at brake deactivation

Value range	Setting	Description
0,000...0,010 m/s	0,005 m/s	

LF.43 Level overspeed

Value range	Setting	Description
0,000...18,000 m/s	auto	The displayed value is 110 % of the maximum speed (LF.01).

Parameter description

LF.44 Deceleration check level

Value range	Setting	Description
0,000...15,000 m/s	auto	The displayed value is 96 % of the rated speed LF.22).

LF.45 Level „running open doors“

Value range	Setting	Description
0,000...0,300 m/s	0,250 m/s	Defines the maximum approach speed, on falling below this speed the doors can open.

LF.46 Speed deviation mode

This parameter serves as control, whether the motor speed can follow the actual speed. The monitoring is active only in closed-loop operation with motor encoder. The tripping level is adjusted with LF.47. If the function is assigned to a digital input, a warning is given.

Value range	Setting	Description
0	x	No switch off when error. The output condition „speed deviation warning“ is set.
1		Inverter switches off the modulation with error E.hSd (high speed difference). The output condition „speed deviation warning“ is set.

LF.47 Speed deviation level

Value range	Setting	Description
0...30 %	10 %	The value in percent refers to the selected speed. The detection takes place in constant run only.

LF.48 Speed deviation tripping time

Value range	Setting	Description
0,000...10,000 s	3,000 s	Adjustment of the time between detection of a speed deviation and tripping of the error E.hSd (LF.46 = 1).

LF.49 Motor + Inverter Overheat-function (OH)

This parameter activates the temperature monitoring of motor and inverter. Precondition for the motor monitoring is the connection of a motor temperature sensor to the terminals T1/ T2. When the heat sink of the inverter reaches a temperature of 90°C, the error E.OH is triggered and the drive is stopped. If the function is assigned to a digital output, a warning is given. At a temperature of 75°C the output is reset and the drive continues to run. The display shows the warning message „OH“.

Value range	Setting	Description
0	x	No error switch-off at overtemperature. The output condition „motor or inverter excess temperature“ is set.
1		When the heat sink of the inverter reaches a temperature of 90°C, the error E.OH is triggered and the drive is stopped. At a temperature of 75°C the error is reset and the drive continues to run. The display shows the warning message „OH“. At an excess temperature of the motor the drive behaves according to LF.50. The output condition „motor or inverter excess temperature“ is set immediately.


LF.50 Drive OH Delay time

If a drive shall still be made despite a hot motor, a delay time between warning and triggering the excess temperature error can be adjusted with this parameter. After the adjusted time has expired the inverter switches off the modulation with error E.dOH.

Value range	Setting	Description
0 s	x	After detection of motor excess temperature the current ride is still completed, before the inverter switches off the modulation with „E.dOH“.
1...3600 s		After detection of motor excess temperature the adjusted time is waited for before the inverter switches off the modulation with error „E.dOH“.

LF.60 Display levelling distance

Value range	Setting	Description
0,0...264,0 cm	-	The time of constant drive in leveling speed (VL) is measured and displayed after each run in unit "cm".



Levelling distance optimization V_N

With the levelling distance optimization the levelling path becomes shorter by the entered value. 3...5 cm levelling path are sufficient. Measuring the levelling distance with LF.60.

LF.61 Levelling path optimization V_N

Value range	Setting	Description
0,0...200,0 cm	0,0 cm	Out of operation at ogive function.

LF.62 Levelling path optimization V_1

Value range	Setting	Description
0,0...200,0 cm	0,0 cm	

LF.63 Levelling path optimization V_2

Value range	Setting	Description
0,0...200,0 cm	0,0 cm	

LF.64 Levelling path optimization V_3

Value range	Setting	Description
0,0...200,0 cm	0,0 cm	

Parameter description

3.6 Positioning mode

Display	Name	Setting Range	Default Setting
LP.00	Display	„POSI“	-
LP.01	Ogive function	0...2	0
LP.02	Minimum deceleration distance (calculated)	0,0...6553,5 cm	auto
LP.03	Deceleration distance (measured)	-3276,7...3276,7 cm	0,0 cm
LP.04	Correction distance	0,0...6553,5 cm	10,0 cm
LP.10	Interface for position feedback	1...2	1
LP.11	Current position encoder High	0...65535 Ink	0 Inc
LP.12	Current position encoder Low	0...65535 Ink	0 Inc
LP.13	Counting direction position	0...1	0
LP.17	Set position High display	0...65535 Ink	0 Inc
LP.18	Set position Low display	0...65535 Ink	0 Inc
LP.19	Reference point position High	0...65535 Ink	0 Inc
LP.20	Reference point position Low	0...65535 Ink	0 Inc
LP.21	Scaling encoder 1 increments High	0...65535 Ink	0 Inc
LP.22	Scaling encoder 1 increments Low	0...65535 Ink	0 Inc
LP.23	Scaling encoder 1 distance	0...65535 mm	0,0 mm
LP.24	Scaling encoder 2 increments High	0...65535 Ink	0 Inc
LP.25	Scaling encoder 2 increments Low	0...65535 Ink	0 Inc
LP.26	Scaling encoder 2 distance	0...65535 mm	0,0 mm
LP.27	Display ratio of encoder 1 to encoder 2	0,00...99,99	1,00
LP.28	Path between current position and reference point High	0...999 m	0 m
LP.29	Path between current position and reference point Low	0...999 mm	0 mm
LP.30	Approach speed for end stopping positions	0,000...10,000 m/s	0,000 m/s
LP.31	Approach path for end stopping positions	0,0...100,0 cm	0,0 cm
LP.34	Teach-in-mode	0...2	0
LP.40	Position index	0...31	0
LP.41	Position value High	0...±999 m	0 m
LP.42	Position value Low	0...±999 mm	0 mm

LP.00 Display of current parameter group „POSI“

LP.01 Ogive function

Input	Setting	Function	Description
0	x	off	With switched off ogive function the acceleration at the deceleration point is aborted immediately. With this parameter the ogive function is activated or a calibration run according to following description is carried out.
1		Calibration run	
2		active	

There are three possibilities to execute the ogive function:

Ogive run


- with levelling path (DOL= digital ogive with leveling speed)
- with direct approach (DODA = digital ogive with direct approach)
- with direct approach and correction Direkteinfahrt shortly before the stopping position (DODAC = digital ogive with direct approach and correction)

Ogive run with levelling path (DOL= digital ogive with leveling speed)

This operating mode is recommended

- for all conventional control with levelling switches.
- if control run-times lead to large tolerances.
- if strong slip develops on the leading sheave.
- if speed signal are noisy.
- if the shaft signals are not accurately installed.
- if mechanical transient processes must be waited for.

The procedure is active as long as a levelling speed entered in LF.21 is larger than 0 m/s in LF.21.



Following conditions must be created:

- Adjust/install deceleration points on all floors and for both directions equally.
- Distance of the deceleration points as far away as possible from the floor, so that a pleasant ogive rounding is possible.

Distinctive features of ogive run with levelling path:

- The F5-lift optimizes the levelling path principally to 5 cm.
- This also applies to the run with rated speed.
- ADA-function (auto deceleration adaption): If the change-over from VN to VL takes place too late at higher floors, the F5-lift calculates a driving curve with steeper deceleration in order not to overrun the stopping position.

Start-up:

- Check whether Lb.4 = 1 is adjusted (Factory setting)
- Enter deceleration path in LP.3
- In case of unknown distances (e.g. renovation) carry out a calibration run, for that adjust LP.1 = 1 and perform a normal drive. The distance between deceleration point and levelling switch is measured.
- For a checkup compare input value with the calculated deceleration path in LP.2. Here the required minimum deceleration path is displayed (see mapping: Distance „s3“ + 5 cm). The value in LP.3 always must be larger or equal to the value in LP.2.
- If the deceleration curve is subsequently adjusted „softer“, check again whether value LP.2 is smaller than value LP.3.
- Switch LP.1 to 2. Thereby the value from LP.3 is accepted and the ogive function is activated.

Trouble-shooting:

- If LP.2 is larger than LP.3, increase the deceleration distance and correction in LP.3 or adjust a „harder“ deceleration curve.
- If the lift overruns the floor, an error in the measuring system of your shaft encoding exists.
- If the levelling path of 5 cm should be too short, enter a smaller value in LP.3. Reduce LP.3 by as many cm as the levelling path shall become longer.


Parameter description

Ogive run with direct approach (DODA = digital ogive with direct approach)

This operating mode is recommended

- if the change-over of the speed inputs takes place precisely and fast (ca. 1 ms)
- if the mentioned problems at ogive run with levelling path do not exist. Otherwise it result in non-levelling.

The procedure is activated by adjusting the levelling speed LF.21 to 0 m/s.



Start-up:


- Check whether Lb.4 is adjusted to 1 (factory setting).
- Check whether LF.21 is = 0 m/s.
- Enter path of deceleration in LP.3. The path of deceleration in LP.3 must match the position of the deceleration points in the shaft to the millimeter. It is measured from the deceleration point to the levelling position/door threshold.
- Activate ogive run with LP.1=2.

Ogive run with direct approach and correction shortly before the stopping position (DODAC = digital ogive with direct approach and correction)

This operating mode is recommended

- if only minor system errors (up to 3 cm) need to be adjusted.

With this procedure ca. 10...15 cm before the stopping position a digital input is set on the frequency inverter, by which the actual residual distance is detected.



Start-up:

- Check whether Lb.4 is adjusted to 1 (factory setting).
- Check whether LF.21 is set to 0 m/s.
- Adjust Lb.10 to 2 (customer-specific input assignment)
- Adjust Lb.12 to 9 (assignment of correction input is terminal X2A.17)
- Enter path of deceleration in LP.3. It is measured from the deceleration point to the levelling position/door threshold. The path of deceleration in LP.3 must match the position of the deceleration points in the shaft to the millimeter.
- All correction points must have exactly the same distance (residual distance) to the stopping position.
- The path of correction (residual distance) must be entered accurately to the millimeter in LP.4.
- Activate ogive run with LP.1=2.

LP.02 Minimum deceleration distance (calculated)

Value range	Setting	Description
0,0...6553,5 cm	auto	only display

LP.03 Deceleration distance (measured)

Value range	Setting	Description
-3276,7...3276,7 cm	0,0 cm	Distance from deceleration point to levelling signal.

LP.04 Correction distance

Value range	Setting	Description
0,0...6553,5 cm	10,0 cm	

LP.10 Interface for position feedback

Input	Setting	Interface	Description
1	x	X3A	Adjustment of the encoder input for the position feedback. For the ogive run the adjustment is taken from LC.01.
2		X3B	

LP.11 Current position encoder 1 High

LP.12 Current position encoder 1 Low

Value range	Setting	Description
0...65535 Ink	0 Ink	Display of the current position values on encoder input 1.

LP.13 Counting direction encoder 1

Input	Setting	Counting direction	Description
0	x	normal	
1		inverted	

LP.14 Current position encoder 2 High

LP.15 Current position encoder 2 Low

Value range	Setting	Description
0...65535 Ink	0 Ink	Display of the current position value on encoder input 2.

LP.16 Counting direction encoder 2

Input	Setting	Counting direction	Description
0	x	normal	
1		inverted	

LP.17 Set position High display

LP.18 Set position Low Display

Value range	Setting	Description
0...65535 Ink	0 Ink	Display of set position.

LP.19 Reference point positin High

LP.20 Reference point position Low

Value range	Setting	Description
0...65535 Ink	0 Ink	Input of the absolute position of the reference point.

Parameter description

LP.21 Scaling encoder 1 increments High

LP.22 Scaling encoder 1 increments Low

LP.23 Scaling encoder 1 distance

Value range	Setting	Description
LP.21: 0...65535 InK	0 InK	With this parameter the scaling of encoder 1 is defined. The larger the selected distance at the input, the more accurate is the scaling.
LP.22: 0...65535 InK	0 InK	
LP.23: 0...65535 mm	0,0 mm	

LP.24 Scaling encoder 2 increments High

LP.25 Scaling encoder 2 increments Low

LP.26 Scaling encoder 2 distance

Value range	Setting	Description
LP.24: 0...65535 InK	0 InK	With this parameter the scaling of encoder 2 is defined. The larger the selected distance at the input, the more accurate is the scaling.
LP.25: 0...65535 InK	0 InK	
LP.26: 0...65535 mm	0,0 mm	

LP.27 Display ratio of encoder 1 to encoder 2

Value range	Setting	Description
0,00...99,99	1,00	Shows the transmission ration of motor encoder to shaft encoder.

LP.28 Path between current position and reference point High

LP.29 Path between current position and reference point Low

Value range	Setting	Description
LP.28: 0...999 m	0 m	The sum of these parameters describes the distance from the actual position to the reference point.
LP.29: 0...999 mm	0 mm	

LP.30 Approach speed for end stopping positions

Value range	Setting	Description
0,000...10,000 m/s	0,000 m/s	

LP.31 Approach path for end stopping positions

Value range	Setting	Description
0,0...100,0 cm	0,0 cm	

LP.34 Teach-in-Mode

Input	Setting	Description
0	x	Normal positioning operation, Tech-in-Mode is switched off.
1		With input X2A.17 the actual position is saved under the adjusted position index.
2		With input X2A.17 the actual position is saved as reference point.

LP.40 Position index

Value range	Setting	Description
0...31	0	Preselection of up to 32 position values (0...31), that can be saved under LP.41 and 42. Position index 0 always corresponds to the lowest stopping position.

LP.41 Position value High

LP.42 Position value Low

Value range	Setting	Description
LP.41: 0...±999 m LP.42: 0...±999 mm	0 m 0 mm	The sum of these two parameters describes the position value belonging to the position index. If the positions have been saved only roughly in the Teach-in-Mode, a manual correction of the position values is possible. If the cabin stands too high, the appropriate Low-part is decreased. If the cabin stands too low, the appropriate Low-part is increased. It is unimportant from which direction the stopping position is approached.

Parameter description

3.7 Information, indications and measured values

Display	Name	Unit	Default setting
LI.00	Display	„InFo“	-
LI.01	Inverter status	-	-
LI.03	Set speed	min ⁻¹	-
LI.04	Actual speed	min ⁻¹	-
LI.05	Set frequency	Hz	-
LI.06	Actual frequency	Hz	-
LI.07	Actual car speed	m/s	-
LI.08	Floor distance	cm	-
LI.09	Set torque	Nm	-
LI.10	Actual torque display	Nm	-
LI.11	Apparent current	A	-
LI.12	Actual load	%	-
LI.13	Peak load	%	-
LI.14	Actual DC link voltage	V	-
LI.15	Peak value DC link voltage	V	-
LI.16	Active parameter set	-	-
LI.17	Terminal input status	-	-
LI.18	Terminal output status	-	-
LI.19	Overload integrator (OL)	%	-
LI.20	Heat sink temperature	°C	-
LI.21	Operating hour counter	h	-
LI.22	Modulation hour meter	h	-
LI.23	Display of refeed energy	kWh	-
LI.24	Modulation factor	%	-
LI.30	Inverter type	-	-
LI.31	Inverter rated current	A	-
LI.32	Serial number Date	DD.MM.Y	-
LI.33	Serial number Counter	-	-
LI.34	Software version Inverter	-	-
LI.35	Software date Inverter	DD.MM.Y	-
LI.36	Software version Operator	-	-
LI.37	Software date Operator	DD.MM.Y	-
LI.38	Software version Interface	-	-
LI.39	Software date Interface	-	-
LI.40	Last error	-	-
LI.41	Last error (t-1)	-	-
LI.42	Last error (t-2)	-	-
LI.43	Last error (t-3)	-	-
LI.44	Last error (t-4)	-	-
LI.45	Last error (t-5)	-	-
LI.46	Last error (t-6)	-	-
LI.47	Last error (t-7)	-	-
LI.48	Last error (t-8)	-	-
LI.50	AN1 display before amplification	%	-
LI.51	AN1 display after amplification	%	-
LI.52	AN2 display before amplification	%	-
LI.53	AN2 display after amplification	%	-

LI.00 Display of current parameter group „InFo“

LI.01 Inverter status

This parameter shows the current status (e.g. constant run, acceleration counter-clockwise rotation) of the inverter. You find a table of all status and error messages in the annex.

LI.03 Set speed

Display	Description
0...±4000 rpm	Display of the current setpoint value. For control reasons the set speed is also displayed, if the control release or the direction of rotation is not switched. If no direction of rotation is given, the set speed for clockwise rotation (forward) is displayed.

LI.04 Actual speed

Display	Description
0...±4000 rpm	Display of the current motor speed (encoder channel 1). For control reasons the set speed is also displayed, if the control release or the direction of rotation is not switched. A counter-clockwise rotating field (reverse) is represented by a negative sign. Precondition for the correct display value is the in-phase connection of the motor and the correct adjustment of the encoder increments as well as the direction of rotation.

LI.05 Set frequency

Display	Description
0...±400 Hz	Display of the current setpoint value. For control reasons the set frequency is also displayed, if the control release or the direction of rotation is not switched. If no direction of rotation is given, the set frequency for clockwise rotation (forward) is displayed.

LI.06 Actual frequency

Display	Description
0...±400 Hz	Display of the current output frequency. A counter-clockwise rotating field (reverse) is represented by a negative sign. Precondition for the correct display value is the in-phase connection of the motor.

LI.07 Actual speed

Display	Description
0...±20 m/s	Display of the current speed of the lift. For control reasons the actual speed is also displayed, if the control release or the direction of rotation is not switched. A counter-clockwise rotating field (reverse) is represented by a negative sign. Precondition for the correct display value is the in-phase connection of the motor and the correct basic setting.

LI.08 Floor distance

Display	Description
0...xxx cm	Indicates the last travel distance from start to stop.

LI.09 Set torque

Display	Description
0...xxx Nm	

Parameter description

LI.10 Actual torque display

Display	Description
0...xxx Nm	The displayed value corresponds to the current motor torque in Nm. The value is calculated from the active current. Due to common type variations and temperature drifts of the motor tolerances of up to 30 % are possible in the base speed range. Basic requirement for the torque display is the adjustment of the motor data. If the real motor data deviate strongly from the name plate data, the operating performance can be optimized by entering the real data. For the start-up the adjustment of the name plate data is sufficient.

LI.11 Apparent current

Display	Description
0...1000A	Display of the current motor apparent current.

LI.12 Actual load

Display	Description
0...200 %	

LI.13 Peak load

Display	Description
0...200 %	

LI.14 Actual DC link voltage

Display	Description			
0...1000 V	Display of the current DC link voltage in volt. Typical values are:			
	V-class	Normal operation	Overvoltage (E.OP)	Undervoltage (E.UP)
	230 V	300...330 VDC	ca. 400 VDC	ca. 216 VDC
	400 V	530...620 VDC	ca. 800 VDC	ca. 240 VDC

LI.15 Peak value DC link voltage

Display	Description
0...1000 V	This parameters makes it possible to determine short-term voltage rises within an operating cycle. For that purpose the highest value that occurred is stored. The peak value memory can be cleared by pressing the key UP, DOWN or ENTER and over Bus by writing any value onto this parameter. Switching off the inverter also results in the deletion of the memory.

LI.16 Active parameter set

Display	Description
0...7	Display of the parameter set, in which the frequency inverter currently is.

LI.17 Terminal input status

Decimal value	Input	Function
1	X2A.16	Display of the currently activated digital inputs. The logical levels at the digital inputs and at the internal inputs are indicated, independent of the following linkage. A certain decimal value is given out for each digital input. If several inputs are activated, the sum of the decimal value is displayed.
2	X2A.17	
4	X2A.14	
8	X2A.15	
16	X2A.10	
32	X2A.11	
64	X2A.12	
128	X2A.13	
256	internal A	
512	internal B	
1024	internal C	
2048	internal D	

LI.18 Terminal output status

Decimal value	Output	Function
1	X2A.18	Display of the currently set external and internal digital outputs. A certain value is given out for each digital output. If several outputs are activated, the sum of the decimal value is displayed.
2	X2A.19	
4	X2A.24...26	
8	X2A.27...29	
16	internal A	
32	internal B	
64	internal C	
128	internal D	

LI.19 Overload integrator (OL)

Value range	Description
0...100 %	To prevent overload errors (E.OL) (load reduction in time), the internal meter reading of the OL-counter can be made visible with this parameter. At 100 % the inverter switches off with error „E.OL“. The error can be reset after a cooling down phase (blinking display „E.nOL“).

LI.20 Heat sink temperature

Value range	Description
0...150 °C	The parameter displays the current heat sink temperature of the inverter.

LI.21 Operating hour counter

Value range	Description
0...65535 h	The operating hour counter shows how long the inverter was switched on. The displayed value includes all operating phases. On reaching the maximum value (ca. 7.5 years) the display stays on the maximum value.

LI.22 Modulation hour meter

Value range	Description
0...65535 h	The modulation hour counter shows how long the inverter was active (power modules activated). On reaching the maximum value (ca. 7.5 years) the display stays on the maximum value.

Parameter description

LI.23 Display of refeed energy

Value range	Description
0...65535 kWh	Display of the refeed energy during generatoric operation. On the basis of this value it can be calculated, whether the use of a refeed unit would be worth it. For that purpose the actual resistance value of the brake resistor must be entered in Lb.18.

LI.24 Modulation factor

Value range	Description
0...110 %	The modulation factor shows the output voltage in percent. 100% correspond to the input voltage (unloaded). At a value above 100 % the inverter operates with overmodulation.

LI.30 Inverter type

Bit	Meaning	Meaning			
0	Inverter size		binary-coded, e.g. 00101 for size 05		
1					
2					
3					
4					
5	Voltage class	0	230 V	1	400 V
6	Phases	0	single-phase	1	3-phase
7	free				
8	Housing Sizes	0	A-housing	7	H-housing
9		1	B-housing	10	K-housing
10		2	C-housing	15	P-housing
11		3	D-housing	17	R-housing
12		4	E-housing	20	U-housing
		6	G-housing	22	W-housing
13	Control	0	G-control	3	S-control
14		1	M-control	4	A-control
15		2	B-control		

LI.31 Inverter rated current

Value range	Description
0...710A	Display of the inverter rated current in A. The value is calculated from the power section identifier and cannot be changed.

LI.32 Serial number Date

Value range	Description
0...65535	The parameter shows the date of production in the format „DD.MM.Y“.

LI.33 Serial number Counter

Value range	Description
0...65535	The parameter shows the consecutive number of the production date from LI.32.

LI.34 Software version Inverter

Value range	Description
0,00...9,99	Display of the software version number of the inverter.

LI.35 Software date Inverter

Value range	Description
0...65535	Display of the software date of the inverter in the format „DD.MM.Y“.

LI.36 Software version Operator

Value range	Description
0,00...9,99	Display of the software version number of the operator.

LI.37 Software date Operator

Value range	Description
0...65535	Display of the software date of the operator in the format „DD.MM.Y“.

LI.38 Software version Interface

Value range	Description
0,00...9,99	Display of the software version number of the encoder interface.

LI.39 Software date Interface

Value range	Description
0...65535	Display of the software date of the encoder interface in the format „DD.MM.Y“.

LI.40 Last error

Value range	Description
0...255	The parameter stores the last error that occurred. E.UP is not stored. The error messages are described in the annex „Error Diagnosis“.

Parameter description

- LI.41 Last Error (t-1)
- LI.42 Last Error (t-2)
- LI.43 Last Error (t-3)
- LI.44 Last Error (t-4)
- LI.45 Last Error (t-5)
- LI.46 Last Error (t-6)
- LI.47 Last Error (t-7)
- LI.48 Last Error (t-8)

Value range	Description																																																																
0000...5FFFh	<p>The parameters LI.41...48 show the last eight errors that occurred. The oldest error is in LI.48. If a new error occurs, it is stored in LI.41. All other errors are moved one parameter further. The oldest error (LI.48) is cancelled. The display of the error takes place in the most significant word (Bit 12...15).</p> <p>Between errors of the same type (e.g. twice OC) the time difference is determined. It is stored in the three low-order words. The display is hexadecimal.</p> <table><tr><th>Error</th><th colspan="3">Time difference</th><th rowspan="2">Value</th></tr><tr><th>Bit 15...12</th><th>Bit 11...8</th><th>Bit 7...4</th><th>Bit 3...0</th></tr><tr><td>x</td><td>0</td><td>0</td><td>0</td><td>0 min</td></tr><tr><td>x</td><td>0</td><td>0</td><td>1</td><td>1 min</td></tr><tr><td>x</td><td>:</td><td>:</td><td>:</td><td>:</td></tr><tr><td>x</td><td>F</td><td>F</td><td>E</td><td>4094 min</td></tr><tr><td>x</td><td>F</td><td>F</td><td>F</td><td>>4095 min</td></tr><tr><td>0</td><td>x</td><td>x</td><td>x</td><td>no error</td></tr><tr><td>1</td><td>x</td><td>x</td><td>x</td><td>E.OC</td></tr><tr><td>2</td><td>x</td><td>x</td><td>x</td><td>E.OL</td></tr><tr><td>3</td><td>x</td><td>x</td><td>x</td><td>E.OP</td></tr><tr><td>4</td><td>x</td><td>x</td><td>x</td><td>E.OH</td></tr><tr><td>5</td><td>x</td><td>x</td><td>x</td><td>E.OHI</td></tr></table>	Error	Time difference			Value	Bit 15...12	Bit 11...8	Bit 7...4	Bit 3...0	x	0	0	0	0 min	x	0	0	1	1 min	x	:	:	:	:	x	F	F	E	4094 min	x	F	F	F	>4095 min	0	x	x	x	no error	1	x	x	x	E.OC	2	x	x	x	E.OL	3	x	x	x	E.OP	4	x	x	x	E.OH	5	x	x	x	E.OHI
Error	Time difference			Value																																																													
Bit 15...12	Bit 11...8	Bit 7...4	Bit 3...0																																																														
x	0	0	0	0 min																																																													
x	0	0	1	1 min																																																													
x	:	:	:	:																																																													
x	F	F	E	4094 min																																																													
x	F	F	F	>4095 min																																																													
0	x	x	x	no error																																																													
1	x	x	x	E.OC																																																													
2	x	x	x	E.OL																																																													
3	x	x	x	E.OP																																																													
4	x	x	x	E.OH																																																													
5	x	x	x	E.OHI																																																													
Example	<p>The display shows following values:</p> <p>LI.41: 3000</p> <p>LI.42: 2000</p> <p>LI.43: 4023</p> <p>LI.44: 4000</p> <p>LI.45...48: 0000</p>																																																																
Description	<p>The last error that occurred is stored in LI.41. The table shows for the most significant hex-value "3" the error E.OP (overvoltage).</p> <p>Before that the error E.OL (LI.42=2xxx) occurred. Because it concerns two different errors, no time difference was stored.</p> <p>In LI.43 and LI.44 the error E.OH is stored. Since these errors are of the same type, a time difference (here „023“) is stored in the three low-order words of LI.43. The hexadecimal value of 23 corresponds to a time difference of 35 minutes in decimal.</p> <p>No errors are stored in LI.45...48.</p>																																																																

LI.50 AN1 Display before amplification

Value range	Description
0...65535	<p>The parameter shows the value of the analog signal AN1 before the characteristic amplification in percent. Depending on the setpoint setting the displayed value of 0...±100 % corresponds to 0...±10 V, 0...±20 mA or 4...20 mA.</p>

LI.51 AN1 Display after amplification

Value range	Description
0...±400 %	The parameter shows the value of the analog signal AN1 after running through the characteristic amplification in percent. The value range is limited to ±400 %.

LI.52 AN2 Display before amplification

Value range	Description
0...±100 %	The parameter shows the value of the analog signal AN2 before the characteristic amplification in percent. Depending on the setpoint setting the displayed value of 0...±100 % corresponds to 0...±10 V, 0...±20 mA or 4...20 mA.

LI.53 AN2 Display after amplification

Value range	Description
0...±400 %	The parameter shows the value of the analog signal AN2 after running through the characteristic amplification in percent. The value range is limited to ±400 %.

3.8 Adjustment of analog inputs and outputs

Display	Name	Setting Range	Default setting
LA.00	Display	„AnLog“	-
LA.01	AN1 setpoint selection	0...2	0
LA.02	AN1 interference filter	0...4	0
LA.03	AN1 zero point hysteresis	0...±10V	0,2V
LA.04	AN1 amplification	0,00...±20,00	1,00
LA.05	AN1 Offset X	0,0...±100,0%	0,0%
LA.06	AN1 Offset Y	0,0...±100,0%	0,0%
LA.07	AN1 lower limit	0,0...±400,0%	-400,0%
LA.08	AN1 upper limit	0,0...±400,0%	400,0%
LA.09	AN2 setpoint selection	0...2	0
LA.10	AN2 interference filter	0...4	0
LA.11	AN2 zero point hysteresis	0...±10V	0,2V
LA.12	AN2 amplification	0,00...±20,00	1,00
LA.13	AN2 Offset X	0,0...±100,0%	0,0%
LA.14	AN2 Offset Y	0,0...±100,0%	0,0%
LA.15	AN2 lower limit	0,0...±400,0%	-400,0%
LA.16	AN2 upper limit	0,0...±400,0%	400,0%
LA.17	Selection REF-input/AUX-function	32768	2112
LA.23	Rope weight	0...500 kg	0

LA.00 Display of the current parameter group „AnLog“

LA.01 AN1 Setpoint selection

Input	Setting	Signal	Description
0	x	0...±10V	Depending on the setting the analog input can process the listed setpoint signals.
1		0...±20 mA	
2		4...20 mA	

LA.02 AN1 Interference filter

Input	Setting	Average value from	Description
0	x	none	A query of the analog signal takes place every millisecond. The interference filter shall suppress interferences and ripples of the input signal, by forming the average value from 2, 4, 8 or 16 scanned values for further processing.
1		2 values	
2		4 values	
3		8 values	
4		16 values	

LA.03 AN1 zero point hysteresis

Value range	Setting	Description
0...±10 %	0,2 %	Through capacitive as well as inductive coupling on the inputs lines or voltage fluctuations of the signal source, the motor connected to the inverter can drift („vibrate“) during standstill in spite of the analog input filter. It is the job of the zero point hysteresis to suppress this. The parameter masks out the analog signal in the adjusted value range. The value applies to both directions of rotation. If a negative percentage is adjusted, the hysteresis acts in addition to the zero point also around the current setpoint value. Setpoint changes are accepted only if they are larger than the adjusted hysteresis.
<p><i>Fig. LA.03: Zero Point Hysteresis</i></p>		<p>for further signal processing</p>

LA.04 AN1 amplification

Value range	Setting	Description
0,00...±20,00	1,00	The amplification of the input signal is adjusted with this parameter. At an amplification of 1.00 the input value corresponds to the output value.
<p><i>Fig. LA.04: Amplification of the analog input signal</i></p>		<p>output value (Out)</p>
<p>Formula for the calculation of the output value</p>		$\text{Out} = \text{amplification} \cdot (\text{In} - \text{Offset X}) + \text{Offset Y}$

LA.05 AN1 Offset X

Value range	Setting	Description
0,0...±100,0 %	0,0 %	The parameter shifts the input characteristic on the X-axis.

Parameter description

LA.06 AN1 Offset Y

Value range	Setting	Description
0,0...±100,0%	0,0%	This parameter shifts the input characteristic on the Y-axis.

LA.07 AN1 lower limit

LA.08 AN1 upper limit

Value range	Setting	Description
0,0...±400,0	LA.07 -400,0 LA.08 +400,0	The parameter serves for the limitation of the analog signal AN1 after the amplifier stage. As no interacting locking exists, it must be observed, that the lower limit is adjusted smaller than the upper limit. (Exception F5-M: In case of lower limit > upper limit then output value = lower limit).
<p><i>Fig. LA.07/08: Limitation of the analog input signal AN1</i></p>		

LA.09 AN2 setpoint selection

Input	Setting	Signal	Description
0	x	0...±10V	Depending on the setting the analog input can process the listed setpoint signals.
1		0...±20mA	
2		4...20mA	

LA.10 AN2 interference filter

Input	Setting	Average value from	Description
0	x	none	A query of the analog signal takes place every millisecond. The interference filter shall suppress interferences and ripples of the input signal, by forming the average value from 2, 4, 8 or 16 scanned values for further processing.
1		2 values	
2		4 values	
3		8 values	
4		16 values	

LA.11 AN2 zero point hysteresis

Value range	Setting	Description
0...±10%	0,2%	see LA.03

LA.12 AN2 amplification

Value range	Setting	Description
0,00...±20,00	1,00	see LA.04

LA.13 AN2 Offset X

Value range	Setting	Description
0,0...±100,0 %	0,0 %	The parameter shifts the input characteristic on the X-axis.

LA.14 AN2 Offset Y


Value range	Setting	Description
0,0...±100,0 %	0,0 %	The parameter shifts the input characteristic on the Y-axis.

LA.15 AN2 lower limit

LA.16 AN2 upper limit

Value range	Setting	Description
0,0...±400,0	LA.15 -400,0 LA.16 +400,0	The parameter serves for the limitation of the analog signal AN2 after the amplifier stage. As no interacting locking exists, it must be observed, that the lower limit is adjusted smaller than the upper limit. (Exception F5-M: In case of lower limit > upper limit then output value = lower limit).

Fig. LA.15/16:
Limitation of the analog
input signal AN2



LA.17 Sselection REF-input/AUX-function

To allow further expansions not all values are defined in the bit groups. Undefined values have the same function as the value 0. The sum of the values is to be entered.

Bit	Input	Setting	Function	Description
0...2	0	x	AN1	Selection of the analog input (AN1, AN2, AN3) as REF analog
	1		AN2	
	2		AN3	
3...5	0	x	Source1	Mode of the AUX-function
	8		Source1+ Source2	
	16		Source1 • (100 % + Source2)	
	24		Source1 • Source2	
	32		Source1 absolute	
6...10	0		AN1	Selection of Source1 for the AUX-function
	64	x	AN2	
	128		Setpoint value in percent	
	192		Motor potentiometer	
	256		Technology controller	
	320		AN3	
11...15	0		AN1	Selection of Source2 for the AUX-function
	2048	x	AN2	
	4096		Setpoint value in percent	
	6144		Motor potentiometer	
	8192		Technology controller	

3.9 Adjustment of pretorque function

1) Preparations

- Enter motor data
- Connect load weighing equipment to X2A.3 and X2A.4
- Switch on the pretorque with Lb.7 =1
- Drive the cabine to the middle of the shaft
- Remain at the same position in the shaft when carrying out the measurements
- Carry out measurements during standstill of the motor after the brake has released
- Adjust the brake release time to 3s to get a better measurement

2) Measurement with empty cabine

- Measure the signal of the load weighing equipment with LI.52. This value „L1“ is displayed in percent.
- Measure the torque including the sign with LI.10.
- Calculate the torque "T1" in percent according to formula: $T1 = LI.10 \cdot 100 / \text{motor rated torque}$.

3) Measurement with 100% load in the cabine

- Measure the signal of the load weighing equipment with LI.52. This value „L2“ is displayed in percent.
- Measure the torque including the sign with LI.10.
- Calculate the torque "T2" in percent according to formula: $T2 = LI.10 \cdot 100 / \text{motor rated torque}$.

4) Calculate the amplification according to formula $LA.12 = (T1-T2)/(L1-L2)$.

5) Calculate the Offset according to formula $LA.14 = LA.12 \cdot L1 - T1$.

6) Enter the calculated values in LA.12 and LA.14.

Examples

Example 1:	Payload	2000 kg		
	Speed	1 m/s		
	Motor rated torque	1200 Nm		
	Counterweight balance	50 %		
Empty cabine	LI.52 = L1 = 0 % (0V)	LI.10 = +1200 Nm	T1 = +100 %	
Full cabine	LI.52 = L2 = 100 % (10V)	LI.10 = -1200 Nm	T2 = -100 %	
Gain	$LA.12 = (100 \% - (-100 \%)) / (0 \% - 100 \%) = -2$			
Offset	$LA.14 = -2 \cdot 0 \% - 100 \% = -100 \%$			

Example 2:	Payload	2000 kg		
	Speed	1 m/s		
	Motor rated torque	1000 Nm		
	Counterweight balance	45 %		
	Load weighing signal has an Offset of -0,5V and can give out only 8V at 100 %.			
Empty cabine	LI.52 = L1 = -5 % (-0,5V)	LI.10 = 1080 Nm	T1 = +108 %	
Full cabine	LI.52 = L2 = 80 % (+8V)	LI.10 = -1320 Nm	T2 = -132 %	
Gain	$LA.12 = (108 \% - (-132 \%)) / (-5 \% - 80 \%) = -2,82$			
Offset	$LA.14 = -2,82 \cdot (-5 \%) - 108 \% = -93,9 \%$			

Example 3: Same system data as in example 2, but the installed motor is rotated by 180°.

Empty cabine	LI.52 = L1 = -5 %	LI.10 = -1080 Nm	T1 = -108 %
Full cabine	LI.52 = L2 = 80 %	LI.10 = +1320 Nm	T2 = +132 %

Gain LA.12 = $(-108\% - 132\%) / (-5\% - 80\%) = 2,82$
 Offset LA.14 = $-2,82 \cdot (-5\%) - (-108\%) = +93,9\%$

LA.23 Rope weight

Value range	Setting	Description
0...500 kg	0 kg	Enter the weight of the free-hanging part of the suspension rope at maximum length.

4 Start-up

Adjust the parameters in ascending order, because by doing so partial pre-adjustments of the unit are initiated. Start with the basic settings (Lb-parameter). Store the adjusted data by pressing the „Enter“-key.

4.1 Start-up of an asynchronous motor without speed encoder with gearbox.

The following procedure is recommended for the start-up of the COMBIVERT F5 Lift with a gearbox-fitted asynchronous motor:

Lb.03: Selection of the appropriate motor type (Lb.03=AELG)

Lb.05: Select the mode of setpoint setting

Ld.01

to

Ld.06: Enter the motor data according to the name plate.

Ld.07: Enter winding resistance (observe directions for Ld.07).

Ld.13: Select a current limit to protect the drive against overload during acceleration.

Ld.21: If necessary, adjust current limit, to protect the UPS (uninterruptible power supply) against overload.

LF.01

to

LF.05: Adjust the data of the elevator.

LF.20

to

LF.27: Adjustment of the corresponding speeds.

LF.30

to

LF.36: Adjustment of the drive profile.

LF.40: Adjustment of the brake release time. A time that is too short causes a starting jerk against the brake. A time that is too long causes a rolling back after the brake is released. Experience values: 0.2...0.5 s.

LF.41: Adjustment of the brake apply time. A time that is too short causes a rolling back before the brake is completely applied. A time that is too long results in a dropout-delay of the main contactors. Experience values: 0.3...0.7 s.

LF.49: If the motor temperature shall be monitored, enter the corresponding values.

Carry out following checks/optimizations during some test rides:

- Load-dependent driving can be optimized by lowering the rated motor speed in steps of 5 rpm.
- Measure the motor speed during an inspection ride with a hand-held tacho. It should nearly be the same speed at „Empty-up“ and „Empty-down“.
- Deviations within the range of 10...20 rpm are normal.
- The rolling back at releasing the brake or at stopping can be optimized by increasing LF.16 in steps of 0.5%.

4.2 Start-up of an asynchronous motor with speed encoder and gearbox

Attention! The delivery status of COMBIVERT is the unregulated mode. Thus the driving comfort may be impaired. The speed-/vector-controlled operation takes place only after the input of all relevant data by activating LF.10.

Lb.03: Selection of the appropriate motor type (Lb.03=AEG)

Lb.05: Select the mode of setpoint setting

Ld.01

to

Ld.06: Enter the motor data according to the name plate.

Ld.11: If necessary, limit the maximum torque for normal operation.

Ld.20: Possible limitation of the maximum torque for UPS operation, to protect the UPS (uninterruptible power supply) against overload..

LC.12:

Adjust the increments per revolution of the motor encoder.

LF.01

to

LF.05: Adjust the data of the elevator.

LF.20

to

LF.27: Adjustment of the corresponding speeds.

LF.30

to

LF.36: Adjustment of the drive profile.

LF.40: Adjustment of the brake release time. A time that is too short causes a starting jerk against the brake. A time that is too long causes the rolling back after the brake is released. Experience values: 0.2...0.5 s.

LF.41: Adjustment of the brake apply time. A time that is too short causes a rolling back before the brake is completely applied. A time that is too long results in a dropout-delay of the main contactors. Experience values: 0.3...0.7 s.

LF.49: If the motor temperature shall be monitored, enter the corresponding value.

Carry out following checks/optimizations during some test rides:

- Is the desired travel direction (up/down) maintained?
- Compare setpoint speed LI.03 with actual speed LI.04. The sign of both speed displays in the same travel direction must be the same (positive is not displayed). If the sign is not equal, an encoder track change must be made with LC.13. In addition to that the travel direction can also be changed:
- Optimization of the load transfer by increasing LF.13 in steps of 500, if the drive turns away too much on releasing the brake.

4.3 Start-up of a synchronous motor with speed encoder without gearbox

- Lb.01: Enter the password
Lb.03: Select the appropriate motor type: Lb. 3=SEGL
Lb.05: Select the mode of setpoint setting.
Lb.10: Decide, whether you want to assign other functions to the digital in-/outputs.
Lb.18: If you want to know the energy losses on the braking resistor, enter the value of the brake resistor
Ld.01
to
Ld.09: Enter the motor data according to the name plate.
Ld.12: Possibly adjust torque limit, to protect the drive against overload during acceleration.
Ld.20: Possibly adjust torque load, to protect the UPS (uninterruptible power supply) against overload.
LC.12: Enter the increments per revolution of the motor encoder.
LC.14: If a speed encoder is used, that possesses an adequate number of commutation signals appropriate to the pole-pair number, adjust LC.14=1.
LC.16: Enter the system position value. If it is not known, it must be calibrated with LC.15.
LF.01
to
LF.05: Enter the data for the elevator.
LF.03: Set gear reduction ratio to „1“ .
LF.20
to
LF.27: Setting of the corresponding speeds.
LF.30
to
LF.36: Setting the value for the drive profile.
LF.40: Set the brake release time. A time that is too short causes a starting jerk against the brake. A time that is too long delays the start. Experience values: 0.3...0.8 s.
LF.41: Set the brake apply time. A time that is too short causes a rolling back before the brake is completely applied. A time that is too long results in a dropoutdelay of the main contactors. Experience values: 0.3...0.7 s.

Carry out the following checks/optimizations during some test rides:

- Rolling back upon releasing the brake or at stopping can be optimized by increasing LF.13 in steps of 500.
- For fast plants it may be necessary to use the torque precontrol, to ensure a perfect load transfer.

5. Error diagnosis

At KEB COMBIVERT **error messages** are always represented with an "E." and the appropriate error code in the display. Error messages cause the immediate deactivation of the modulation. Restart possible only after reset or autoreset.

Malfunctions are represented with an "A." and the appropriate message. Reactions to malfunctions can vary.

Operating messages during the start/up phase start with an "S".

In the following the display indications and their cause are described.

Display	COMBIVIS		Meaning
Status Messages			
bbL	base block	76	Power modules for motor de-excitation locked
bon	close brake	85	Brake control, brake engaged (see chapter 6.9)
boFF	open brake	86	Brake control, brake released (see chapter 6.9)
Cdd	Calculate drive	82	Measurement of the motor stator resistance.
dcb	DC brake	75	Motor is decelerated by a DC-voltage at the output.
dLS	Low speed / DC brake	77	Modulation is switched off after DC-braking (see chapter 6.9 "DC-Braking").
FAcc	Forward acceleration	64	Acceleration with the adjusted ramps in clockwise direction of rotation.
Fcon	Forward constant	66	Acceleration / deceleration phase is completed and it is driven with constant speed / frequency in clockwise direction of rotation.
FdEc	Forward deceleration	65	It is stopped with the adjusted ramp times in clockwise direction of rotation.
HCL	Hardware current limit	80	The message is output if the output current reaches the hardware current limit.
LAS	LA stop	72	This message is displayed if during acceleration the load is limited to the adjusted load level.
LdS	Ld stop	73	This message is displayed if during deceleration the load is limited to the adjusted load level or the DC-link current to the adjusted voltage level.
LS	Low speed	70	No direction of rotation pre-set, modulation is off.
nO_PU	Power unit not ready	13	The power circuit is not ready respectively is not identified by the control.
nOP	No operation	0	Control release (terminal ST) is not switched.
PA	Positioning active	122	This message is displayed during a positioning process.
PLS	Low speed / power off	84	No modulation after Power-Off.
PnA	Position not reachable	123	The specified position cannot be reached within the pre-set ramps. The abort of the positioning can be programmed.
POFF	Power off function	78	Depending on the programming of the function (see chapter 6.9 „Power-off Function) the inverter restarts automatically upon system recovery or after a reset.
POSI	Positioning	83	Positioning function active (F5-G).
rAcc	Reverse acceleration	67	Acceleration with the adjusted ramp times in anti-clockwise direction of rotation.
rcon	Reverse constant	69	Acceleration / deceleration phase is completed and it is driven with constant speed / frequency in clockwise direction of rotation.
rdEc	Reverse deceleration	68	It is stopped with the adjusted ramp times in anti-clockwise direction of rotation.
rFP	Ready for positioning	121	The drive signals that it is ready to start the positioning process.
SLL	Stall	71	This message is displayed if during constant operation the load is limited to the adjusted current limit.
SrA	Search for ref. active	81	Search for reference point approach active.

continued on next page

Error diagnosis

Display	COMBIVIS		Meaning
SSF	Speed search	74	Speed search function active, that means that the inverter attempts to synchronize onto a running down motor.
STOP	Quick stop	79	The message is output if as response to a warning signal the quick-stop function becomes active.
Error Messages			
E. br	Error! Brake control	56	Error: can occur in the case of switched on brake control (see chapter 6.9.5), if the load is below the minimum load level (Pn.43) at start up or the absence of an engine phase was detected the load is too high and the hardware current limit is reached
E.buS	Error! Watchdog	18	Adjusted monitoring time (Watchdog) of communication between operator and PC / operator and inverter has been exceeded.
E.Cdd	Error! Calculation drive data	60	Error: During the automatic motor stator resistance measurement.
E.co1	Error! Counter overflow 1	54	Counter overflow encoder channel 1.
E.co2	Error! Counter overflow 2	55	Counter overflow encoder channel 2.
E.dOH	Error! Drive overheat	9	Error: Overtemperature of motor PTC. Error can only be reset at E.ndOH, if PTC is again low-resistance. Causes: resistance at the terminals T1/T2 >1650 Ohm motor overloaded line breakage to the temperature sensor
E.dri	Error! Driver relay	51	Error: Driver relay. Relay for driver voltage on power circuit has not picked up even though control release was given.
E.EEP	Error! EEPROM defective t	21	After reset the operation is again possible (without storage in the EEPROM)
E. EF	Error! External fault	31	Error: External error. Is triggered, if a digital input is being programmed as external error input and trips.
E.EnC	Error! Encoder cable	32	Cable breakage on resolver or incremental encoder
E.Hyb	Error! Hybrid	52	Invalid encoder interface identifier.
E.HybC	Error! Hybrid changed	59	Error: Encoder interface identifier has changed, it must be confirmed over ec.0 or ec.10.
E.iEd	Error! Input error detect	53	Hardware error at the NPN-/PNP-changeover or the start/stop measurement
E.InI	Error! Initialisation MFC	57	MFC not booted.
E.LSF	Error! Load shunt fault	15	Load-shunt relay has not picked up. Occurs for a short time during the switch-on phase, but must automatically be reset immediately. If the error message remains the following causes may be applicable: load-shunt defective input voltage wrong or too low high losses in the supply cable braking resistor wrongly connected or damaged braking module defective
E.ndOH	No error drive overheat	11	Motor temperature switch or PTC at the terminals T1/T2 is again in the normal operating range. The error can then be reset.
E.nOH	No error over heat power module	36	Temperature of the heat sink is again in the permissible operating range. The error can be reset now.
E.nOHI	No error internal overheat	7	No longer overheating in the interior E.OHI, interior temperature has fallen by at least 3°C

continued on next page

Display	COMBIVIS		Meaning
E.nOL	No error overload	17	No more overload, OL-counter has reached 0%; after the error E.OL a cooling phase must elapse. This message appears upon completion of the cooling phase. The error can be reset now. The inverter must remain switched on during the cooling phase.
E.nOL2	No error overload 2	20	The cooling time has elapsed. The error can be reset.
E. OC	Error! Overcurrent	4	Occurs, if the specified peak current is exceeded. Causes:
			acceleration ramps too short
			the load is too big at turned off acceleration stop and turned off constant current limit
			short-circuit at the output
			short-circuit at the output
			deceleration ramp too short
			motor cable too long
E. OH	Error! Overheat power module	8	EMC
			DC brake at high ratings active (see 6.9.3)
			Error: Overtemperature of power module. Error can only be reset at E.nOH. Causes:
			insufficient air flow at the heat sink (soiled)
E.OH2	Error! Motor protection	30	ambient temperature too high
			ventilator clogged
E.OHI	Error! Internal overheat	6	Electronic motor protective relay has tripped.
E. OL	Error! Overload (lxt)	16	Error: Overheating in the interior: error can only be reset at E.nOHI, if the interior temperature has dropped by at least 3 °C.
			Error: Overload error can only be reset at E.nOL, if OL-counter reaches 0% again. Occurs, if an excessive load is applied longer than for the permissible time (see technical data). Causes:
			poor control adjustment (overshooting)
			mechanical fault or overload in the application
			inverter not correctly dimensioned
E.OL2	Error! Overload 2	19	motor wrongly wired
			encoder damaged
E. OP	Error! Overvoltage	1	Occurs if the standstill constant current is exceeded (see technical data and overload characteristics). The error can only be reset if the cooling time has elapsed and E.nOL2 is displayed.
			Voltage in the DC-link circuit too high. Occurs when the DC bus voltage rises above the permissible value. Causes:
			poor controller adjustment (overshooting)
			input voltage too high
			interference voltages at the input
E.OS	Error! Over speed	58	deceleration ramp too short
			braking resistor defective or too small
E.PFC	Error! Power factor control	33	The speed lies outside the specified limits.
E.PrF	Error! Prot. rotation forward	46	Error in the power factor control
E.Prr	Error! Prot. rotation reverse	47	The drive has driven onto the right limit switch. Programmed response „Error, restart after reset“ (see chapter 6.7 „Response to errors or warning messages“).
			The drive has driven onto the left limit switch. Programmed response „Error, restart after reset“ (see chapter 6.7 „Response to errors or warning messages“).

continued on next page

Error diagnosis

Display	COMBIVIS		Meaning
E. Pu	Error! Power unit	12	General power circuit fault (e. g. fan)
E.Puci	Error! Unknown power unit	49	Error: During the initialization the power circuit could not be recognized or was identified as invalid.
E.Puch	Error! Power unit changed	50	Error: Power circuit identification was changed; with a valid power circuit this error can be reset by writing to SY.3. If the value displayed in SY.3 is written, only the power-circuit dependent parameters are reinitialized. If any other value is written, then the default set is loaded. On some systems after writing Sy.3 a Power-On-Reset is necessary.
E.PUCO	Error! Power unit communication	22	Error: Parameter value could not be written to the power circuit. Acknowledgement from LT <> OK
E.PUIN	Error! Power unit invalid	14	Error: Software version for power circuit and control card are different. Error cannot be reset (only at F5-G B-housing)
E.SbuS	Error! Bus synchron	23	Synchronization over sercos-bus not possible. Programmed response „Error, restart after reset“.
E.SET	Error! Set	39	It has been attempted to select a locked parameter set. Programmed response „Error, restart after reset“.
E.SLF	Error! Software limit switch forward	44	The target position lies outside of the limit defined with the right software limit switch. Programmed response „Error, restart after reset“.
E.SLr	Error! Software limit switch reverse	45	The target position lies outside of the limit defined with the left software limit switch. Programmed response „Error, restart after reset“.
E. UP	Error! Underpotential	2	Undervoltage (DC-link circuit) Occurs when the DC bus voltage drops below the permissible value. Causes:
			input voltage too low or instable
			inverter rating too small
			voltage losses through wrong cabling
			the supply voltage through generator / transformer breaks down at very short ramps
			at F5-G housing B E.UP is also displayed if no communication takes place between power circuit and control card.
E.UPh	Error! Phase failure	3	jump factor (Pn.56) too small
			if a digital input was programmed as external error input with error message E.UP (Pn.65).
E.UPh	Error! Phase failure	3	One phase of the input voltage is missing (ripple-detection)
Warning messages			
A.buS	Warning! Watchdog	93	Watchdog for communication between operator/control card or operator/PC has responded. The response to this warning can be programmed.
A.dOH	Warning! Drive overheat	96	The motor temperature has exceeded an adjustable warning level. The switch off time is started. The response to this warning can be programmed. This warning can be generated only with a special power circuit.
A. EF	Warning! External fault	90	This warning is triggered via an external input. The response to this warning can be programmed.
A.ndOH	All-clear! Drive overheat	91	The motor temperature is again below the adjusted warning level. The switch off time is stopped.
A.nOH	All-clear! Overheat power module	88	The heat sink temperature is again below the adjusted warning level.
A.nOHI	All-clear! Internal overheat	92	The temperature in the interior of the inverter is again below the warning threshold.
A.nOL	All-clear! Overload	98	OL counter has reached 0 %, the warning “overload“ can be reset.
A.nOL2	All-clear! Overload 2	101	The cooling time after “Warning! Overload during standstill“ has elapsed. The warning message can be reset.

continued on next page

Display	COMBIVIS		Meaning
A. OH	Warning! Overheat power module	89	A level can be defined, when it is exceeded this warning is output. The response to this warning can be programmed.
A.OH2	Warning! Motor protection	97	Warning: electronic motor protective relay has tripped. The response to this warning can be programmed.
A.OHI	Warning! Internal overheat	87	The temperature in the interior of the inverter lies above the permissible level. The switch off time was started. The programmed response to this warning message is executed.
A. OL	Warning! Overload	99	A level between 0 and 100 % of the load counter can be adjusted, when it is exceeded this warning is output. The response to this warning can be programmed.
A.OL2	Warning! Overload 2	100	The warning is output when the standstill continuous current is exceeded (see technical data and overload characteristics). The response to this warning can be programmed. The warning message can only be reset after the cooling time has elapsed and A.nOL2 is displayed.
A.PrF	Warning! Prot. rotation forward	94	The drive has driven onto the right limit switch. The response to this warning can be programmed.
A.Prr	Warning! Prot. rotation reverse	95	The drive has driven onto the left limit switch. The response to this warning can be programmed.
A.SbuS	Warning! Bus synchron	103	Synchronization over sercos-bus not possible. The response to this warning can be programmed.
A.SET	Warning! Set	102	It has been attempted to select a locked parameter set. The response to this warning can be programmed.
A.SLF	Warning! Software limit switch forward	104	The target position lies outside of the limit defined with the right software limit switch. The response to this warning can be programmed.
A.SLr	Warning! Software limit switch reverse	105	The target position lies outside of the limit defined with the left software limit switch. The response to this warning can be programmed.

Messages during the start-up phase

S.cc	contactor closed	143	Contact control input not reset
S.co	contactor open	141	Setpoint selection without contactor control input
S.Ebd	both directions	144	Both directions of motion actuated simultaneously
S.Ebr	Error brake	142	Brake does not release
S.io	illegal operation	140	Setpoint selection without control release



Karl E. Brinkmann GmbH

Försterweg 36-38 • D-32683 Barntrup
fon: +49 5263 401-0 • fax: +49 5263 401-116
net: www.keb.de • mail: info@keb.de

KEB Antriebstechnik GmbH & Co. KG

Wildbacher Str. 5 • D-08289 Schneeberg
fon: +49 3772 67-0 • fax: +49 3772 67-281
mail: info@keb-combidrive.de

KEB Antriebstechnik Austria GmbH

Ritzstraße 8 • A-4614 Marchtrenk
fon: +43 7243 53586-0 • fax: +43 7243 53586-21
net: www.keb.at • mail: info@keb.at

KEB Antriebstechnik

Herenveld 2 • B-9500 Geraadsbergen
fon: +32 5443 7860 • fax: +32 5443 7898
mail: vb.belgien@keb.de

KEB CHINA Karl E. Brinkmann GmbH

(Xinmao Building, Caohejing Development Zone)
No. 99 Tianzhou Road (No.9 building, Room 708)
CHN-200233 Shanghai, P.R. China
fon: +86 21 54503230-3232 • fax: +86 21 54450115
net: www.keb.cn • mail: info@keb.cn

KEB CHINA Karl E. Brinkmann GmbH

No. 36 Xiaoyun Road • Chaoyang District
CHN-10027 Beijing, P.R. China
fon: +86 10 84475815 + 819 • fax: +86 10 84475868
net: www.keb.cn • mail: hotline@keb.cn

KEB Antriebstechnik Austria GmbH

Organizační složka
K. Weise 1675/5 • **CZ-370 04** České Budějovice
fon: +420 387 699 111 • fax: +420 387 699 119
net: www.keb.cz • mail: info.keb@seznam.cz

KEB España

C/ Mitjer, Nave 8 - Pol. Ind. LA MASIA
E-08798 Sant Cugat Segrarriques (Barcelona)
fon: +34 93 897 0268 • fax: +34 93 899 2035
mail: vb.espana@keb.de

Société Française KEB

Z.I. de la Croix St. Nicolas • 14, rue Gustave Eiffel
F-94510 LA QUEUE EN BRIE
fon: +33 1 49620101 • fax: +33 1 45767495
net: www.keb.fr • mail: info@keb.fr

KEB (UK) Ltd.

6 Chieftain Buisness Park, Morris Close
Park Farm, Wellingborough **GB-Northants**, NN8 6 XF
fon: +44 1933 402220 • fax: +44 1933 400724
net: www.keb-uk.co.uk • mail: info@keb-uk.co.uk

KEB Italia S.r.l.

Via Newton, 2 • I-20019 Settimo Milanese (Milano)
fon: +39 02 33500782 • fax: +39 02 33500790
net: www.keb.it • mail: kebitalia@keb.it

KEB - YAMAKYU Ltd.

15-16, 2-Chome, Takanawa Minato-ku
J-Tokyo 108-0074
fon: +81 33 445-8515 • fax: +81 33 445-8215
mail: info@keb.jp

KEB Nederland

Leidsevaart 126 • **NL-2013** HD Haarlem
fon: +31 23 5320049 • fax: +31 23 5322260
mail: vb.nederland@keb.de

KEB Polska

ul. Budapesztańska 3/16 • **PL-80-288** Gdańsk
fon: +48 58 524 0518 • fax: +48 58 524 0519
mail: vb.polska@keb.de

KEB Portugal

Avenida da Igreja – Pavilhão A n.º 261 Mouquim
P-4770 - 360 MOUQUIM V.N.F.
fon: +351 252 371318 + 19 • fax: +351 252 371320
mail: keb.portugal@netc.pt

KEB Taiwan Ltd.

No.8, Lane 89, Sec.3; Taichung Kang Rd.
R.O.C.-Taichung City / Taiwan
fon: +886 4 23506488 • fax: +886 4 23501403
mail: info@keb.com.tw

KEB Korea Seoul

Room 1709, 415 Missy 2000
725 Su Seo Dong, Gang Nam Gu
ROK-135-757 Seoul/South Korea
fon: +82 2 6253 6771 • fax: +82 2 6253 6770
mail: vb.korea@keb.de

KEB Sverige

Box 265 (Bergavägen 19)
S-43093 Hälsö
fon: +46 31 961520 • fax: +46 31 961124
mail: vb.schweden@keb.de

KEB America, Inc.

5100 Valley Industrial Blvd. South
USA-Shakopee, MN 55379
fon: +1 952 224-1400 • fax: +1 952 224-1499
net: www.kebamerica.com • mail: info@kebamerica.com