



**5B - BTR M74
AUTO TRANSMISSION**

541






AUTO TRANSMISSION - BTR M74 I (541)

NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL			
			CM	MU	KO	RX
1	AUTO TRANSMISSION - REPLACE	5410100	-	5.8	5.8	5.8
	AUTO TRANSMISSION - OVERHAUL	5410200	-	13.2	13.2	13.2
2	TORQUE CONVERTER - REPLACE	5410300	-	6.0	6.0	6.0
3	SEAL AND/OR HOUSING, CONVERTOR - REPLACE	5410500	-	6.1	6.1	6.1

CM : CHAIRMAN, MU : MUSSO, KO : KORANDO, RX:REXTON

542




AUTO TRANSMISSION - BTR M74 II (542)

NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL			
			CM	MU	KO	RX
1	PUMP ASSEMBLY, FRONT - REPLACE	5420100	-	6.0	6.0	6.0
2	SHAFT ASSEMBLY, INPUT - REPLACE	5420300	-	7.2	7.2	7.2
3	SHAFT AND HUB ASSEMBLY, OVER DRIVE - REPLACE	5420500	-	7.3	7.3	7.3
4	DISC AND CYLINDER ASSEMBLY - REPLACE	5420700	-	7.3	7.3	7.3
5	CLUTCH ASSEMBLY - REPLACE	5420900	-	7.5	7.5	7.5
6	OUTPUT SHAFT ASSEMBLY - REPLACE	5421100	-	6.9	6.9	6.9

CM : CHAIRMAN, MU : MUSSO, KO : KORANDO, RX:REXTON

543









AUTO TRANSMISSION - BTR M74 III (543)

NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL			
			CM	MU	KO	RX
1	SERVO, FRONT - REPLACE	5430100	-	0.6	0.6	0.6
2	SERVO, REAR - REPLACE	5430300	-	0.7	0.7	0.7
3	OIL SEAL AND/OR MANUAL VALVE DETENT LEVER - REPLACE	5430500	-	0.6	0.6	0.6
4	INHIBITOR SWITCH - REPLACE	5430700	-	0.5	0.5	0.5
5	ROD ASSEMBLY, ACTUATING - REPLACE	5430900	-	0.7	0.7	0.7
6	GASKET, ADAPTER HOUSING - REPLACE	5431100	-	1.2	1.4	1.2
7	HOUSING ASSEMBLY, ADAPTER - REPLACE	5431300	-	1.2	1.4	1.2
8	OIL SEAL, ADAPTER HOUSING - REPLACE	5431500	-	1.2	1.4	1.2

CM : CHAIRMAN, MU : MUSSO, KO : KORANDO, RX:REXTON

544



AUTO TRANSMISSION - BTR M74 IV (544)							
NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL				
			CM	MU	KO	RX	
1	OIL, A/T - REPLACE	5440100	-	1.4	1.5	1.4	
2	VALVE BODY - REPLACE	5440300	-	1.5	1.9	1.5	
	VALVE BODY - OVERHAUL	5440400	-	3.1	3.1	3.1	
3	SOLENOID, VALVE BODY - REPLACE	5440500	-	1.6	1.6	1.6	
	A - Replace each additional	5440600	-	0.1	0.1	0.1	
4	GASKET, OIL PAN - REPLACE	5440700	-	0.9	1.4	0.9	
5	FILTER, A/T OIL - REPLACE	5440900	-	1.5	1.4	1.5	
6	PAN, OIL - REPLACE	5441100	-	0.9	1.4	0.9	
7	WIRING, A/T SOLENOIL - REPLACE	5441300	-	1.1	4.9	1.1	
8	PIPE, OIL COOLER - REPLACE	One	5441400	-	0.4	0.4	0.4
		Two	5441410	-	0.3	0.3	0.3
9	HOSE, OIL COOLER - REPLACE		5441500	-	0.3	0.3	0.3
		Two	5441510	-	0.3	0.3	0.3

CM : CHAIRMAN, MU : MUSSO, KO : KORANDO, RX:REXTON